Roku® TV Replacement Remote

User Manual

See reverse for easy-to-follow instructions and exclusive deals.

Thank you for your purchase!

Instructions made easy

Read instructions or watch easy-to-follow video.

Scan code or visit byjasco.com/66814i

Register your product

Receive exclusive deals and register your product.

Scan code or visit byjasco.com/deals

For additional CE products, visit our website. **www.byjasco.com**

Like our product?
Leave a review on your favorite retailer website or amazon.com.

Having Problems?
Let us know how we can help.

Call **1-800-654-8483** between 7AM-8PM, M-F, Central Time.

Setup

Preprogrammed for immediate use with Roku-enabled TVs*. Simply insert two (2) AA batteries (not included) and you're ready to enjoy your favorite shows. Alkaline batteries are recommended for this remote.

*An Insignia or Sharp Roku-enabled TV may require programming. Additionally, if you wish to program the remote to operate a Roku streaming player rather than a Roku TV, please see the Programming Instructions section for details.

Battery Installation

1. Press arrow on back of remote and slide cover downward to remove.
2. Insert the batteries, making sure to match the (+) (-) polarity inside the compartment.
3. Replace cover and slide it upward until it clicks into place.

NOTE: If your remote is not operating properly, replace the batteries with new ones.

Battery Precautions

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH, etc.) batteries.
- Always remove old, weak or worn-out batteries promptly and recycle or dispose of them in accordance with local and national regulations.

Battery Saver

Your remote automatically turns off if the buttons are held down for more than 8 seconds. This saves battery life if your remote gets stuck in a place where the buttons remain depressed (e.g., between sofa cushions).

Code Saver

You have up to 10 minutes to change the batteries in your remote without losing the codes you have programmed.

Troubleshooting

Remote does not operate your device

- Make sure the batteries are fresh and installed correctly.
- Aim the remote directly at your device and make sure there are no obstructions between the remote and the device.
- Remote may not be compatible with your device.

Reset to Factory Settings

1. Press and hold the SETUP button until the red light stays on.
2. Press the REWIND button 4 times. The red light will blink twice.

Button Functions

1. **Power** - Turns device ON/OFF
2. **Setup** - Used to program the remote
3. **Up/down/left/right menu navigation**
4. **OK** - Selects menu items
5. **Back** - Returns to previous menu/screen
6. **Home** - Returns to the home screen to access streaming features
7. **Options (*)** - Displays additional options
8. **Rewind, play/pause, fast forward**
9. **Volume up/down**
10. **Channel up/down**
11. **Mute** - Mutes sound
12. **App** - Accesses top apps like Netflix, Amazon Prime, Hulu and more
13. **Instant replay** - Repeats previous few seconds, then resumes play

This product and its sellers are not affiliated with Roku®. There is no endorsement or sponsorship by non-affiliated brands provided or implied. All brand names and products listed/shown are trademarks of their respective owners.

Programming Instructions

Insignia and Sharp Roku TVs: Some Insignia and Sharp models may need additional programming. Use the included Code List and follow the steps below.

Roku Streaming Players: This remote can operate either a Roku TV or a Roku streaming player. It does not work with Roku streaming sticks. Programming is required for use with compatible Roku streaming players. Use the included Code List and follow the steps below.

1. In the Code List (included with remote), circle the 4-digit codes for the type and brand of device you wish to control.
2. Press and hold down the SETUP button until the remote's red light turns on.
3. Use the number buttons indicated in the diagram above to enter the first 4-digit code circled in Step 1. The red light will then turn off.
4. Point the remote at the device and test the buttons. If they don't work as expected, repeat Steps 2-4 with the next circled code.

Programming notes

- Some codes may operate only a few device functions, so test other codes for more functionality.
- Keep your device codes for future reference.

66814 v1 1/22

MADE IN CHINA

GE is a trademark of General Electric Company and is under license by Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114.

This Jasco product comes with a limited-lifetime warranty. Visit www.byjasco.com for warranty details.

Questions? Contact our U.S.-based Consumer Care at 1-800-654-8483 between 7AM-8PM, M-F, Central Time.

FCC Statement

Suppliers Declaration of Conformity | Model #: 66814 | Jasco Products Co., 10 E. Memorial Rd., Oklahoma City, OK 73114, www.byjasco.com

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ICES-3(B)/NMB-3(B).

Declaración de la FCC

Declaración de conformidad de proveedores | Modelo n.º: 66814 | Jasco Products Co., 10 E. Memorial Rd., Oklahoma City, OK 73114, www.byjasco.com

Este dispositivo cumple con la Parte 15 de las normas de la FCC. Su funcionamiento está sujeto a las siguientes dos condiciones: (1) este dispositivo no podrá causar interferencias perjudiciales, y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que puedan causar un funcionamiento no deseado.

NOTA DE LA FCC: El fabricante no se responsabiliza por ninguna interferencia de radio o TV causada por modificaciones no autorizadas a este equipo. Tales modificaciones podrían anular el derecho del usuario a hacer uso del equipo.

NOTA: Este equipo se sometió a pruebas y cumple con los límites establecidos para un dispositivo digital Clase B de acuerdo con la Sección 15 de las Normas de la FCC. Dichos límites están diseñados para proporcionar una protección razonable contra la interferencia perjudicial en una instalación residencial. Este equipo genera, usa y puede irradiar energía de radiofrecuencia y, si no se instala y usa de acuerdo con estas instrucciones, podría causar una interferencia perjudicial en las radiocomunicaciones. No obstante, no es posible garantizar que no ocurrirán interferencias en una instalación en particular. Si este equipo causa interferencias perjudiciales en la recepción de radio o televisión, las cuales pueden comprobarse encendiendo y apagando el equipo, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas:

- Reoriente o reubique la antena receptora.
- Aumente la distancia entre el equipo y el receptor.
- Conecte el equipo a una toma de corriente en un circuito diferente al que está conectado el receptor.
- Consulte al distribuidor o a un técnico experimentado de radio/TV para obtener ayuda. ICES-3(B)/NMB-3(B).

Preparación

Preprogramado para uso inmediato con televisores habilitados para Roku*. Simplemente inserte dos (2) pilas AA (no incluidas) y estará listo para disfrutar sus programas favoritos. Se recomiendan pilas alcalinas para este control remoto.

*Un televisor Insignia o Sharp habilitado para Roku puede requerir programación. Además, si desea programar el control remoto para operar un reproductor de transmisión Roku en vez de un televisor Roku, consulte la sección Instrucción de programación para obtener más información.

Colocación de las pilas

1. Presione la flecha en la parte posterior del control remoto y deslice la tapa de las pilas hacia abajo para retirarla.
2. Inserte las pilas asegurándose de que coincidan con la polaridad (+) (-) dentro del compartimiento.
3. Vuelva a colocar la tapa y deslícela hacia abajo hasta que encaje en su lugar.

Nota: Si su control remoto no funciona correctamente, reemplace las pilas por otras nuevas.

Precauciones con las pilas

No coloque pilas nuevas con pilas viejas. No coloque una combinación de pilas alcalinas, estándar (carbono-zinc) o recargables (Ni-Cd, Ni-MH, etc.). Retire siempre las baterías viejas, con poca carga o agotadas de inmediato y recíclelas o deséchelas de acuerdo con las reglamentaciones locales y nacionales.

Ahorro de energía

Su control remoto se apaga automáticamente si los botones se mantienen presionados durante más de 8 segundos. Esto prolonga la vida útil de las pilas si su control remoto se atasca en un lugar donde los botones permanecen presionados (por ejemplo, entre los cojines del sofá).

Protector de códigos

Tiene hasta 10 minutos para cambiar las pilas en su control remoto sin perder los códigos que programó.

Solución de Problemas

El control remoto no opera su dispositivo

- **Asegúrese de que las pilas sean nuevas y estén instaladas correctamente.**
- **Apunte el control remoto directamente a su dispositivo y asegúrese de que no haya obstrucciones entre el control remoto y el dispositivo.**
- **El control remoto puede no ser compatible con su dispositivo.**

Restablecer a la Configuración de Fábrica

1. Mantenga presionado el botón SETUP hasta que la luz roja se mantenga encendida.
2. Presione el botón RETROCEDER 4 veces. La luz roja parpadeará dos veces.

Funciones de los Botones

1. Encendido/Apagado: enciende/apaga el televisor
2. Setup: se usa para programar el control remoto
3. Navegación hacia arriba, abajo, izquierda, derecha
4. OK: selecciona elementos del menú
5. Back: vuelve al menú o pantalla anteriores
6. Home: vuelve a la pantalla de inicio para acceder a las funciones de transmisión
7. Opciones (*): muestra opciones adicionales
8. Retroceder, reproducir/pausa, avanzar rápido
9. Sube/baja el volumen
10. Ir al canal de arriba/abajo
11. Mute: silencia el sonido
12. App: accede a las principales aplicaciones como Netflix, Amazon Prime, Hulu y más
13. Instant replay: repite unos pocos segundos anteriores, luego reanuda la reproducción

Este producto y sus vendedores no está afiliados con Roku®. No se brinda ni se entiende que haya promoción o patrocinio alguno por parte de marcas no afiliadas. Todos los nombres y productos de marca que se enumeran o muestran son marcas registradas de sus respectivos dueños.

Entrada directa de código

Televisores Insignia y Sharp para Roku: Algunos modelos Insignia y Sharp pueden necesitar programación adicional. Use la Lista de códigos incluida y siga los pasos a continuación.

Reproductores de transmisión Roku: Este control remoto puede operar un televisor Roku o un reproductor de transmisión Roku compatible. No funciona con reproductores de transmisión Roku tipo pendrive. Se requiere la programación para el uso con reproductores de transmisión Roku compatibles. Use la Lista de códigos incluida y siga los pasos a continuación.

1. En la Lista de códigos (incluida con el control remoto), encierre en un círculo los códigos de 4 dígitos para el tipo y la marca del dispositivo que desea controlar.
2. Mantenga presionado el botón SETUP hasta que se encienda la luz roja del control remoto.
3. Use los botones de números indicados en el diagrama anterior para ingresar el primer código de 4 dígitos que encerró en un círculo en el Paso 1. La luz roja se apagará.
4. Apunte el control remoto al dispositivo y pruebe los botones. Si no funcionan como esperaba, repita los pasos 2 a 4 con el siguiente código encerrado en un círculo.

Notas sobre la programación

- Algunos códigos pueden operar solo unas pocas funciones del dispositivo, así que pruebe otros códigos para obtener acceso a más funcionalidades.
- Guarde los códigos de su dispositivo para futuras consultas.

HECHO IN CHINA

GE es una marca comercial de General Electric Company con licencia otorgada a Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114.

Este producto de Jasco tiene una garantía de por vida limitada. Visite www.byjasco.com para conocer los detalles de la garantía.

¿Preguntas? Comuníquese al 1-800-654-8483 entre las 7 a. m. y las 8 p. m., de lunes a viernes, hora del centro.