

Bar HD User Manual

UltraPro™
ELITE



COMPATIBLE WITH
NEXTGEN TV
ATSC 3.0 BROADCAST STANDARD





YOU MUST PERFORM A CHANNEL SCAN AFTER INSTALLATION.



CALL Please call before returning to store

Questions? Contact our U.S.-based Consumer Care at 1-800-654-8483 between 7AM-8PM, M-F, Central Time.

See reverse for easy-to-follow instructions and exclusive deals.



PLEASE NOTE: Use only the supplied power supply.



1. Open the TV's setup or settings menu.
2. Select *scan*, *autotune*, *channel search* or *channel scan*, making sure it's set to scan for over-the-air channels rather than cable.
3. Wait for the TV to complete the channel scan.

Tip 1: Consult the TV manual or contact the TV's manufacturer for detailed instructions.

Tip 2: Rescan for over-the-air channels anytime you move the antenna.

Test reception with and without the amplifier if you are within 20 miles of the broadcast tower.

QUESTIONS? ISSUES?
CALL OUR U.S.-BASED EXPERTS AT
1-800-654-8483

Helpful Antenna Tips

Maximize the number of channels by testing the antenna in several locations. **Be sure to run a TV channel scan** in each position. Refer to your TV's instruction manual if necessary.

Position the antenna as high as possible or near a window for best performance.

Visit www.antennaweb.org to determine the available television stations and broadcast tower locations in your area.

⚠ WARNING

RISK OF ELECTRIC SHOCK

- DO NOT USE IN WET LOCATIONS
- KEEP CHILDREN AWAY
- USE INDOORS ONLY
- FULLY INSERT PLUG

RISK OF FIRE

- DO NOT EXCEED ELECTRICAL RATINGS

NOT FOR USE WITH

- AQUARIUMS OR OTHER WATER RELATED PRODUCTS
- GENERATORS AND POWER INVERTERS
- MEDICAL LIFE-SUPPORT PRODUCTS

⚠ CAUTION

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT USE THIS DEVICE WITH A RECEPTACLE IN WHICH THE SLOT OPENINGS DO NOT ALIGN WITH THE BLADES, NOT FOR USE WITH GROUND-FAULT CIRCUIT-INTERRUPTER RECEPTACLES OR RECEPTACLES WITH INDICATOR LIGHTS OR CONTROLS.



58229 V1 01/21

MADE IN CHINA

Distributed by Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114.

This Jasco product comes with a limited-lifetime warranty. Visit www.byjasco.com for warranty details.

Questions? Contact our U.S.-based Consumer Care at 1-800-654-8483 between 7AM-8PM, M-F, Central Time.

Thank you for your purchase!

Instructions made easy



Read instructions or watch easy-to-follow video. Scan code or visit byjasco.com/58229i



Exclusive deals

For deals, to register your purchase and to tell us how we're doing, simply scan the code or visit byjasco.com/deals



Enhance your home entertainment experience at byjasco.com/ce



Like our product? Leave a review on your favorite retailer website or amazon.com



Having problems? Let us know how we can help. Call 1-800-654-8483 between 7AM-8PM, M-F, Central Time.


Manual del usuario de Antena de barra HD

UltraPro[™]
ELITE




1. Conectar

Conecte la antena al amplificador y, luego, el amplificador al televisor.



2. Colocar

Coloque la antena en la ubicación deseada.



3. Buscar

Realice una búsqueda de canales de TV.



1. Abra el menú de configuración o ajustes del televisor.
2. Seleccione buscar, sintonización automática, búsqueda de canales o exploración de canales, asegurándose de que esté configurado para buscar canales de señal abierta en lugar de los de cable.
3. Espere que el televisor complete la búsqueda de canales.

Consejo 1: Consulte el manual del televisor o comuníquese con el fabricante del televisor para obtener instrucciones detalladas.

Consejo 2: Vuelva a realizar una búsqueda de canales de señal abierta cada vez que mueva la antena.

Pruebe la recepción con y sin el amplificador si está en un radio de 32 km de la torre de transmisión.

Consejos útiles con respecto a la antena

Maximice la cantidad de canales probando la antena en varios lugares. **Asegúrese de ejecutar una búsqueda de canales** de televisión en cada posición. Consulte el manual de instrucciones de su televisor si es necesario.

Posicione la antena lo más alto que pueda o cerca de una ventana para el mejor rendimiento.

Visite www.antennaweb.org para determinar las emisoras de televisión disponibles y la ubicación de las torres de transmisión en su área.

¿PREGUNTAS? ¿PROBLEMAS?
CONTACTE CON NUESTROS
EXPERTOS AL
1-800-654-8483

⚠ ADVERTENCIA
RIESGO DE CHOQUE ELÉCTRICO

- NO LO USE EN LUGARES HÚMEDOS
- NO LO DEJE AL ALCANCE DE LOS NIÑOS
- USE SOLAMENTE EN INTERIORES
- INSERTE COMPLETAMENTE EL ENCHUFE

RIESGO DE INCENDIO

- NO EXCEDA LOS LÍMITES ELÉCTRICOS PERMITIDOS

NO PARA USO CON

- ACUARIOS U OTROS PRODUCTOS RELACIONADOS CON EL AGUA
- GENERADORES E INVERSORES DE ENERGÍA
- PRODUCTOS DE APOYO MÉDICO DE VIDA

⚠ PRECAUCIÓN
PARA REDUCIR EL RIESGO DE INCENDIO O CHOQUE ELÉCTRICO, NO LO USE ESTE DISPOSITIVO CON UN RECEPTÁCULO ESO TIENE APERTURAS ENCAJÓ NO ALINEE CON CON LAS HOJAS. NO PARA USO CON LAS RECEPTÁCULOS DE GFCI O RECEPTÁCULOS CON EL INDICADORES DE LUZ O CONTROLA.



CÓMO BUSCAR CANALES

DEBE REALIZAR UNA BÚSQUEDA DE CANALES DESPUÉS DE LA INSTALACIÓN.

LLAMADA
Llame antes de devolver a la tienda

¿Tiene preguntas? Comuníquese con nuestro Servicio al consumidor con sede en EE. UU. al **1-800-654-8483** entre las 7 a. m. y las 8 p. m., hora del centro.

NOTA: Use únicamente la fuente de alimentación

HECHO EN CHINA
Distribuido por Jasco Products Company LLC,
10 E. Memorial Rd., Oklahoma City, Oklahoma 73114.
Este producto de Jasco tiene una garantía de por vida limitada.
Visite www.byjasco.com para conocer los detalles de la garantía.
¿Preguntas? Comuníquese al 1-800-654-8483 entre las 7 a. m. y las 8 p. m. CT (hora del centro).