

Thank you for your purchase!

Instructions made easy



Read instructions or watch easy-to-follow video.

Scan code or visit

<https://byjasco.com/60732i>

Exclusive deals



For deals, to register your purchase and to tell us how we're doing, simply scan the code or visit **byjasco.com/deals**



Discover more Princess décor at **byjasco.com**



Like our product?

Leave a review on your favorite retailer website or amazon.com

Having problems?

Let us know how we can help.
1-800-654-8483
between 7AM-8PM,
M-F, Central Time.



Disney
PRINCESS



**COLOR-CHANGING
Tabletop Lamp**



COLOR-CHANGING Tabletop Lamp

USB POWER

To power your tabletop lamp, insert the included USB power cord into the port on the lamp's base. Then, plug the the USB-A end of the power cord into any standard USB-A adapter (not included). 1A minimum required for the USB-A power adapter.

OPERATION

To turn the lamp ON, and to cycle through each mode, lightly tap the center circle on top of the lamp. Hold your finger on the center circle for three seconds to turn the lamp OFF.

1. White Light Mode:

- The lamp's initial preset mode is HIGH white light
- Tap the center circle to change to MEDIUM white light
- Tap again to change to LOW white light

2. Color-Fade Mode:

- While in LOW white light, tap the center circle again — the lamp will begin to slowly fade through all 12 colors

3. Color-Select™ Mode:

- During Color-Fade Mode, you can manually cycle through each of the 12 colors by repeatedly tapping the center circle
- Color Options — Red, Green, Blue, Orange, Yellow, Lite Green, Turquoise, Light Blue, Light Purple, Dark Purple, Light Pink, Deep Pink

After manually cycling through all 12 colors, the lamp will return to White Light Mode.

NOTE: If you turn the lamp OFF and ON again, the lamp will return to the last selected mode.

MADE IN CHINA

Distributed by Jasco Products Company LLC,
10 E. Memorial Rd., Oklahoma City, OK 73114.

This Jasco product comes with a 90-day limited warranty. Visit www.bjjasco.com for warranty details.

Questions? Contact our U.S.-based Consumer Care at 1-800-654-8483 between 7AM-8PM, M-F, Central Time.



Separate paper from plastic before recycling

SVDC, 1A




Figure A

Figure B

WARNING

- THIS PRODUCT IS NOT A TOY
- NOT INTENDED FOR USE BY CHILDREN
- USE Indoors ONLY
- PLUG ONLY INTO USB SAFETY CERTIFIED TYPE A PORT
- THE INCLUDED USB BARREL CONNECTOR CABLE (FIGURE A) SHOULD ONLY BE USED FOR THIS DEVICE (FIGURE B). IT SHOULD **NOT** BE USED FOR ANY OTHER LIKE ITEMS, EVEN IF THE CABLE CAN BE INSERTED IN THEM.

©Disney

60732-1 EnSp Manual v1 5/15/21

LÁMPARA DE MESA QUE CAMBIA DE COLOR

ALIMENTACIÓN USB

Para encender su lámpara de mesa, inserte el cable de alimentación USB en el puerto de la base de la lámpara. Luego, enchufe el extremo USB-A del cable de alimentación en un adaptador USB-A estándar (no incluido). Se requiere un adaptador de corriente USB-A de 1 A como mínimo.

FUNCIONAMIENTO

Para encender la lámpara, y desplazarse por cada modo, toque el círculo central en la parte superior de la lámpara. Mantenga su dedo en el círculo central durante tres segundos para apagar la lámpara.

1. Modo de luz blanca:

- El modo inicial predeterminado de la lámpara es la luz blanca alta (HIGH)
- Toque el círculo central para cambiar al modo de luz blanca media (MEDIUM)
- Toque nuevamente para cambiar al modo de luz blanca baja (LOW)

2. Modo de atenuación del color:

- Mientras está en la luz blanca baja, toque el círculo central nuevamente, con ello la lámpara comenzará a desplazarse atenuándose lentamente por cada uno de los 12 colores

3. Modo Color-Select™:

- Durante el Modo de atenuación de color, puede desplazarse manualmente por cada uno de los 12 colores tocando repetidamente el círculo central
- Opciones de colores: rojo, verde, azul, naranja, amarillo, verde claro, turquesa, celeste, morado claro, morado oscuro, rosa claro, rosa intenso

Después de desplazarse manualmente por los 12 colores, la lámpara volverá al Modo de luz blanca.

NOTA: Si apaga y enciende la lámpara, esta volverá al último modo seleccionado.




Figure A

Figure B

HECHO EN CHINA

Distribuido por Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, Oklahoma 73114.

Este producto de Jasco tiene una garantía limitada de 90 días. Visite www.bjjasco.com para conocer los detalles de la garantía.

¿Preguntas? Comuníquese al 1-800-654-8483 entre las 7AM y las 8PM CST (hora central estándar).

ADVERTENCIA

- ESTE PRODUCTO NO ES UN JUGUETE
- NO ESTÁ DISEÑADO PARA QUE LOS NIÑOS LO USEN
- SOLO PARA USO EN INTERIORES
- SOLO ENCHUFE EN UN PUERTO USB CON CERTIFICACIÓN DE SEGURIDAD TIPO AUSB TIPO CERTIFICADO UN PUERTO
- EL CABLE DE CONECTOR CILÍNDRICO USB PROVISTO (FIGURA A) SOLAMENTE SE DEBE USAR PARA ESTE DISPOSITIVO (FIGURA B). **NO SE DEBE UTILIZAR CON NINGÚN OTRO ARTÍCULO SIMILAR, A PESAR DE QUE EL CABLE SE PUEDA INSERTAR EN EL.**