

Thank you for your purchase!

Instructions made easy



Read instructions or watch easy-to-follow video.
Scan code or visit <https://byjasco.com/61867i>

Exclusive deals



For deals, to register your purchase and to tell us how we're doing, simply scan the code or visit byjasco.com/deals



Explore more from Power Gear at https://byjasco.com/power_gear



Like our product? Leave a review on your favorite retailer website or amazon.com

Having problems? Let us know how we can help.
1-800-654-8483 between 7AM-8PM, M-F, Central Time.



Battery Operated Decoy Security Camera



See reverse for easy-to-follow instructions and exclusive deals

Battery-Operated Decoy Security Camera

Your Power Gear Decoy Security Camera is designed to fool would-be intruders and keep them away — adding an extra layer of protection to your home. Hold onto this manual for reference later.

Install batteries

1. Remove battery door
2. Take out mounting hardware (not included)
3. Install 2 AAA batteries (not included)

Mounting with tape

1. Clean desired mounting surface of dust and debris
2. Peel paper backing off one side of the double-sided tape
3. Firmly press tape onto back of battery door
4. Reattach battery door and peel off the second paper backing
5. Firmly press decoy camera onto surface with lens on top

Mounting with screws


1. Hold mounting template (or double sided tape) in place and mark screw locations with pencil. Distance between the screw locations should be about 2in
2. Drill pilot holes on each pencil marking using 3/16in. drill bit, then insert the anchors. Screw through the circle indentions using the two long screws provided. Use a #1 Phillips-head screwdriver (do not over-tighten). (Figure A)
3. Hold battery door in place and align the two circle indentions with the anchors. Screw through the circle indentions using the two long screws provided. Use a #1 Phillips-head screwdriver (do not over-tighten). (Figure A)
4. Reattach decoy camera to mounted battery door
5. Insert short screw into base of decoy camera to secure battery door

Figure A



NOTE: This is a decoy camera only and will not record video. Once batteries are installed blue LED will flash at approximately 3.5 second intervals until depleted. The batteries should be replaced when the LED brightness becomes barely visible


MOUNTING TEMPLATE PLANTILLA PARA LA INSTALACIÓN




MADE IN CHINA

Distributed by Jasco Products Company
LLC, 10 E. Memorial Rd., Oklahoma City,
OK 73114.
This Jasco product comes with a 90-day
limited warranty. Visit www.byjasco.com for
warranty details.
Questions? Contact our U.S.-based
Consumer Care at 1-800-654-8483
between 7AM-8PM, M-F, Central Time.

61867 v1 7/21



HECHO EN CHINA
Distribuido por Jasco Products
Company LLC, 10 E. Memorial Rd.,
Oklahoma City, OK 73114.
Este producto de Jasco tiene una
garantía limitada de 90 días. Para más
información sobre la garantía, visite
www.byjasco.com.
Preguntas? Comuníquese al
1-800-654-8483 entre las 7AM y las 8PM
CST (hora central estándar).



NOTA: Esta es solo una cámara señuelo y no grabará video. Una vez que las pilas estén instaladas, el LED azul parpadeará a intervalos de aproximadamente 3.5 segundos hasta que se agoten. Las pilas deben reemplazarse cuando el brillo del LED sea apenas visible

1. Sostenga la plantilla de montaje (o cinta doble faz) en su lugar y marque la ubicación de los tornillos con un lápiz. La distancia entre las ubicaciones de los tornillos debe ser de aproximadamente 2 pulgadas (5 centímetros)
2. Taladre agujeros piloto en cada marca de lápiz con una broca de 3/16 pulgadas (5 milímetros). Luego inserte los anclajes
3. Sostenga la compuerta de las pilas en su lugar y alinee las dos muescas circulares con los anclajes. Atornille a través de las muescas circulares con los dos tornillos largos incluidos. Use un destornillador de cabeza Phillips no. 1 (no lo apriete demasiado).
4. Vuelva a colocar la cámara señuelo en la compuerta de las pilas montada
5. Inserte un tornillo corto en la base de la cámara señuelo para asegurar la compuerta de las pilas

Montaje con tornillos

1. Limpie el polvo y los restos de la superficie de montaje deseada
2. Despegue el papel de un lado de la cinta doble faz
3. Presione firmemente la cinta sobre la parte posterior de la compuerta de las pilas
4. Vuelva a colocar la compuerta de las pilas y retire el papel del otro lado de la cinta
5. Presione firmemente la cámara señuelo sobre la superficie con la lente hacia arriba

Montaje con cinta

1. Retire la compuerta de las pilas
2. Saque el hardware de montaje
3. Instale 2 pilas AAA (no incluidas)

Instale las pilas

Su cámara de seguridad señuelo Power Gear está diseñada para engañar a los posibles intrusos y mantenerlos alejados, lo que agrega una capa adicional de protección a su hogar. Conserve este manual para consultarlo más adelante.

Cámara de seguridad señuelo a pila