


PHILIPS

HD antenna

Audio/video

Portable
antenna



**YOU MUST PERFORM A
CHANNEL SCAN AFTER
INSTALLATION.**



Please call before
returning to store


Questions?

Contact our U.S.-based Consumer
Care at 1-844-816-0320, M-F.

See reverse for easy-to-follow
instructions and exclusive deals.

1. Connect

Connect the antenna to the TV.




NOTE: If your TV does not have a coax cable port, a
converter box is required for installation.


NOTE: This antenna is not weatherproof and should be
stored indoors.

2. Place

Place the antenna in your desired location.




OR



3. Scan

Perform a TV channel scan.



1. Open your TV's *setup* or *settings* menu.
2. Select *scan*, *auto tune*, *channel search* or *channel scan*, making sure your TV is set to scan for over-the-air channels rather than cable.
3. Wait for the TV to complete the channel scan.

Tip 1: Consult the TV manual or contact the TV's
manufacturer for detailed instructions.

Tip 2: Rescan for over-the-air channels anytime you
move the antenna.

Helpful antenna tips

Maximize the number of channels by
testing the antenna in several locations.
Be sure to run a TV channel scan in each
position. Refer to your TV's instruction
manual, if necessary.

Position the antenna as high as possible or
near a window for best performance.

Visit www.antennaweb.org to determine
the available television stations and location
of the broadcast towers in your area.

QUESTIONS? ISSUES?
CALL OUR U.S.-BASED EXPERTS AT
1-844-816-0320

SDV3125B/37 v1 05/25

MADE IN VIETNAM
Philips and the Philips Shield Emblem are
registered trademarks of Koninklijke Philips
N.V. and are used under license. This product
has been manufactured by and is sold
under the responsibility of Jasco Products
Company, and Jasco Products Company LLC,
10 E. Memorial Rd., Oklahoma City, OK 73114
is the warrantor in relation to this product.

This product has a limited-lifetime warranty.
Visit www.philips.com/support for warranty
details.

Questions? Contact our U.S.-based
Consumer Care at 1-844-816-0320, M-F.

PATENTS/PATENTS PENDING
WWW.BYJASCO.COM/PATENTS



**Thank you for
your purchase!**



**Instructions
made easy**
Read instructions
or watch an
easy-to-follow video.

Scan code or visit byjasco.com/859991



**Register your
product**
Receive exclusive
deals and register
your product.

Scan code or visit byjasco.com/deals



For additional CE
products, visit our
website.
www.byjasco.com



Like our product?
Leave a review on your favorite
retailer website or amazon.com.




Having problems?
Let us know how we can help.
Call 1-844-816-0320, M-F.

PHILIPS

HD antenna

Audio/video

Antena Portátil de HD



CÓMO BUSCAR CANALES

DEBE REALIZAR UNA BÚSQUEDA DE CANALES DESPUÉS DE LA INSTALACIÓN.




Llame antes de devolver a la tienda

¿Preguntas? Comuníquese con nuestro servicio de atención al consumidor con sede en EE. UU. Al 1-844-816-0320, de lunes a viernes.

1. Conectar



Conecte la antena al televisor.



NOTA: Si su televisor no dispone de puerto para cable coaxial, necesitará un convertidor para la instalación.

2. Colocar


Coloque la antena en la ubicación deseada.



NOTA: Esta antena no es resistente a la intemperie y debe guardarse en interiores.

3. Buscar

Realice una búsqueda de canales para su TV.



1. Abra la configuración (setup) del TV o el menú configuración (settings).
2. Seleccione buscar (scan), autoajuste (auto tune), búsqueda de canales (channel search) o escaneo de canales(channel scan), asegurándose de que está configurado para buscar canales por aire en lugar de por cable.
3. Espere que el TV complete la búsqueda de canales.

Consejo 1: Consulte el manual del televisor o comuníquese con el fabricante del televisor para obtener instrucciones detalladas.

Consejo 2: Vuelva a realizar una búsqueda de canales de señal abierta cada vez que mueva la antena.

Consejos útiles con respecto a la antena

Optimice la cantidad de canales al colocar la antena en diversas ubicaciones. **Asegúrese de realizar una nueva búsqueda de canales de TV en cada posición.** Consulte el manual de instrucciones de su TV de ser necesario.

Posicione la antena a la mayor altura posible o cerca de una ventana para garantizar su funcionamiento óptimo.

Visite www.antennaweb.org para determinar las estaciones televisivas disponibles y la ubicación de las torres de transmisión de su zona.

¿PREGUNTAS? ¿PROBLEMAS?
CONTACTE CON NUESTROS EXPERTOS AL
1-844-816-0320

HECHO EN VIETNAM

Philips y el emblema de escudo Philips son marcas registradas de Koninklijke Philips N.V. y se usan bajo licencia. Este producto ha sido fabricado y se comercializa bajo responsabilidad de Jasco Products Company y Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114, es el garante en relación a este producto.

Este producto tiene una garantía limitada de por vida. Visite www.philips.com/support para conocer los detalles de la garantía.

¿Preguntas? Comuníquese al 1-844-816-0320, de lunes a viernes.

PATENTES/PATENTES PENDIENTES
WWW.BYJASCO.COM/PATENTS

¡Gracias por su compra!



Registre su producto

Recibe ofertas exclusivas y registra tu producto.

Escanee el código o visite byjasco.com/deals.



Descubra más iluminación innovadora en byjasco.com/ce.



¿Le gusta nuestro producto?
Deje una reseña en el sitio web de su distribuidor favorito o en amazon.com.



¿Tiene algún problema?
Díganos cómo podemos ayudar.
Llame al **1-844-816-0320**, de lunes a viernes.

