

Energizer®

Swivel Touch-Activated Task Light User Manual

BATTERY INSTALLATION:

Open battery compartment and insert 3 AA batteries (not included) noting polarity. Close battery compartment cover.

IMPORTANT:

Different types of batteries or new and used batteries should not be mixed. Exhausted batteries should be removed from the fixture and disposed of properly.

⚠ WARNING

- BATTERIES MAY LEAK HARMFUL LIQUIDS OR IGNITABLE MATERIALS OR EXPLODE CAUSING INJURY AND PRODUCT DAMAGE
- DO NOT MIX OLD AND NEW OR OTHER BATTERY TYPES
- REPLACE ALL BATTERIES AT THE SAME TIME
- REMOVE BATTERIES IF PRODUCT IS TO BE UNUSED FOR EXTENDED PERIODS OF TIME

READ IT OR WATCH IT



READ INSTRUCTIONS OR WATCH EASY-TO-FOLLOW VIDEO. SCAN QR CODE OR VISIT [HTTPS://GOO.GL/9T3Kc](https://goo.gl/9T3Kc).

MADE IN CHINA/HECHO EN CHINA

©2019 Energizer. Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Jasco Products Company, LLC. All other brand names are trademarks of their respective owners. Neither Jasco Products Company, LLC nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.

Contact our U.S.-based Consumer Care at 1-800-654-8483 between 7AM-8PM CST.

90-day warranty. Visit www.byjasco.com for warranty details

38362 Manual v4
12/12/18



KEYHOLE CENTER MARK
Marca central de agujero

5.0"
126 mm

MOUNTING TEMPLATE
PLANTILLA PARA LA INSTALACIÓN



KEYHOLE CENTER MARK
Marca central de agujero

Energizer®

Swivel Touch-Activated Task Light Manual del usuario

INSTALACIÓN DE LAS PILAS:

Abra el compartimiento de las pilas e inserte 3 pilas AA (no incluidas) teniendo en cuenta la polaridad. Cierre la tapa del compartimiento de las pilas.

IMPORTANTE:

No se deben mezclar distintos tipos de pilas ni tampoco las nuevas con las usadas. Las pilas agotadas se deben sacar del aparato y deben desecharse de manera adecuada.

⚠ ADVERTENCIA

- LAS PILAS PUEDEN PERDER LÍQUIDOS PERJUDICIALES O MATERIALES INFLAMABLES, O EXPLOTAR Y CAUSAR LESIONES Y DAÑOS EN LOS PRODUCTOS
- NO COMBINE PILAS VIEJAS Y NUEVAS, NI TIPOS DE PILAS DISTINTAS
- REEMPLACE TODAS LAS PILAS AL MISMO TIEMPO.
- quite las pilas si no usará el producto durante periodos prolongados

©2018 Energizer. Energizer y algunos diseños gráficos son marcas comerciales de Energizer Brands, LLC y subsidiarias relacionadas, que se utilizan bajo la licencia de Jasco Products Company, LLC. Todos los demás nombres de marca que aparecen son marcas comerciales pertenecientes a sus respectivos propietarios. Ni Jasco Products Company, LLC ni Energizer Brands, LLC están relacionados con los propietarios respectivos de sus marcas comerciales.

¿Preguntas? Comuníquese al 1-800-654-8483 entre las 7a.m. y las 8 p.m. CST (hora central estándar)