

LED Lantern User's Guide



battery installation:

The lantern is operated with 6 D cell batteries (not included). Batteries must be installed or replaced in sets of six.


NOTE: If replacing the batteries, remove the old batteries and follow the instructions below.



1. Turn the lantern over and remove the battery cover by twisting the cap counter clockwise.



2. To run the lantern from 6 D cells, fill all six positions noting proper battery polarity.



3. Replace the battery cover by fitting the center plastic column within the base and then twisting the cover clockwise until it clicks firmly into place.

CAUTION

BATTERIES MAY LEAK HARMFUL LIQUIDS OR IGNITABLE MATERIALS OR EXPLODE CAUSING INJURY OR PRODUCT DAMAGE.

- DO NOT MIX OLD AND NEW OR OTHER BATTERY TYPES
- REPLACE ALL BATTERIES AT THE SAME TIME
- REPLACE FULLY DISCHARGED BATTERIES IMMEDIATELY
- REMOVE BATTERIES IF PRODUCT IS TO BE UNUSED FOR EXTENDED PERIOD OF TIME




illustration 1

using the latching handle:

1. To open the handle, depress the raised button near the bottom of the handle. See illustration 1.
2. Fully open the handle.
3. Close handle around object you wish the lantern to hang from. See illustration 2.
4. Open the raised button. Be sure the handle is securely latched before allowing lantern to fully hang on its own. See illustration 3.

- Do not attempt to hang lantern with handle in open position.
- Always be sure to hang the lantern in a safe and secure area.
- Lantern should never be left out in excessive wind.




illustration 2




illustration 3

FCC statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: reorient or relocate the receiving antenna, increase the separation between the equipment and receiver, or connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Made in China

GE is a trademark of General Electric Company and is under license by Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114.

This Jasco product comes with a 5-year limited warranty. Visit www.byjasco.com for details.

Questions? Contact us at 1-800-654-8483 between 7:00AM-8:00PM CST.

usb charging:

Rating: 1A@5V

USB charging port may not charge all devices. Some devices require a proprietary USB power supply.

