


Ultra Edge HD User Manual

Ultra**Pro**[™]
ELITE


1. Connect

Connect the antenna to the TV.



2. Place

Place the antenna in your desired location.



3. Scan

Perform a TV channel scan.



1. Open the TV's setup or settings menu.
2. Select *scan*, *autotune*, *channel search* or *channel scan*, making sure it's set to scan for over-the-air channels rather than cable.
3. Wait for the TV to complete the channel scan.

Tip 1: Consult the TV manual or contact the TV's manufacturer for detailed instructions.

Tip 2: Rescan for over-the-air channels anytime you move the antenna.

Helpful Antenna Tips

Maximize the number of channels by testing the antenna in several locations. **Be sure to run a TV channel scan** in each position. Refer to your TV's instruction manual if necessary.

Position the antenna as high as possible or near a window for best performance.

Visit www.antennaweb.org to determine the available television stations and broadcast tower locations in your area.

QUESTIONS? ISSUES?

CALL OUR U.S.-BASED EXPERTS AT
1-800-654-8483

58676 V1 01/21

MADE IN VIETNAM
Distributed by Jasco Products Company LLC,
10 E. Memorial Rd., Oklahoma City, OK 73114.
This Jasco product comes with a limited-lifetime warranty.
Visit www.byjasco.com for warranty details.
Questions? Contact our U.S.-based Consumer Care at
1-800-654-8483 between 7AM-8PM, M-F, Central Time.

Thank you for your purchase!

Instructions made easy



Read instructions or watch easy-to-follow video.
Scan code or visit **byjasco.com/58676i**



Exclusive deals

For deals, to register your purchase and to tell us how we're doing, simply scan the code or visit **byjasco.com/deals**



Enhance your home
entertainment experience
at **byjasco.com/ce**



Like our product?
Leave a review on your
favorite retailer website
or amazon.com



Having problems?
Let us know how we can help.
Call 1-800-654-8483 between
7AM-8PM, M-F, Central Time.



Please call before
returning to store

Questions? Contact our U.S.-based
Consumer Care at **1-800-654-8483**
between 7AM-8PM, M-F, Central Time.


See reverse for easy-to-follow
instructions and exclusive deals.

Manual del usuario de Antena de HD




1. Conectar

Conecte la antena al televisor.



2. Colocar

Coloque la antena en la ubicación deseada.



3. Buscar

Realice una búsqueda de canales de TV.



1. Abra el menú de configuración o ajustes del televisor.
2. Seleccione buscar, sintonización automática, búsqueda de canales o exploración de canales, asegurándose de que esté configurado para buscar canales de señal abierta en lugar de los de cable.
3. Espere que el televisor complete la búsqueda de canales.

Consejo 1: Consulte el manual del televisor o comuníquese con el fabricante del televisor para obtener instrucciones detalladas.
Consejo 2: Vuelva a realizar una búsqueda de canales de señal abierta cada vez que mueva la antena.

Consejos útiles con respecto a la antena

Maximice la cantidad de canales probando la antena en varios lugares. **Asegúrese de ejecutar una búsqueda de canales** de televisión en cada posición. Consulte el manual de instrucciones de su televisor si es necesario.

Posicione la antena lo más alto que pueda o cerca de una ventana para el mejor rendimiento.

Visite www.antennaweb.org para determinar las emisoras de televisión disponibles y la ubicación de las torres de transmisión en su área.

¿PREGUNTAS? ¿PROBLEMAS?
CONTACTE CON NUESTROS EXPERTOS AL 1-800-654-8483

CÓMO BUSCAR CANALES
DEBE REALIZAR UNA BÚSQUEDA DE CANALES DESPUÉS DE LA INSTALACIÓN.

LLAMADA Llame antes de devolver a la tienda

¿Tiene preguntas? Comuníquese con nuestro Servicio al consumidor con sede en EE. UU. al **1-800-654-8483** entre las 7 a. m. y 8 p. m. de lunes a viernes, hora del centro

HECHO EN VIETNAM
Distribuido por Jasco Products Company LLC,
10 E. Memorial Rd., Oklahoma City, Oklahoma 73114.
Este producto de Jasco tiene una garantía de por vida limitada.
Visite www.byjasco.com para conocer los detalles de la garantía.
¿Preguntas? Comuníquese al 1-800-654-8483 las 7 a. m. y 8 p. m. de lunes a viernes CT (hora del centro).