

Thank you for your purchase!

Instructions made easy



Read instructions or watch easy-to-follow video.

Scan code or visit
<https://byjasco.com/60258i>

Exclusive deals



For deals, to register your purchase and to tell us how we're doing, simply scan the code or visit byjasco.com/deals



Discover more lighting from UltraPro at byjasco.com



Like our product?

Leave a review on your favorite retailer website or amazon.com

Having problems?

Let us know how we can help.
1-800-654-8483
between 7AM-8PM,
M-F, Central Time.



Ultra**Pro**TM



**Motion-Sensing
Bathroom Light**

UltraPro™

Motion-Sensing Bathroom Light

INSTALLATION

BATTERY INSTALLATION:

Remove the cover on the back of the light and install 3 AAA batteries (not included), noting polarity.

TOILET MOUNTING:

Ensure the flexible arm is securely attached into the port above the battery compartment. Bend the flexible arm to form a right angle and securely hook it onto the rim of the toilet bowl. The base of the light will sit outside of the toilet while the arm sits inside.

Note: Make sure that the arm is securely attached before letting go.

WALL MOUNTING:

Remove the flexible arm by sliding it downwards and gently pulling out. Use the keyhole mounts on the base and screws (included) to mount it onto a wall or other flat surface.

Note: Ensure that the mounting location is a dry location and capable of supporting the light.

OPERATION

MOTION SENSING:

This light features both motion sensors and dusk-to-dawn activation. While in low light conditions, the light will automatically turn on when motion is detected within 15ft. and in a 120-degree field. The light will turn OFF after 120 seconds (2 minutes) of inactivity.

COLOR SELECT:

Press the button on the front of the light to change the color of the LED inside the toilet bowl. There are multiple options:

1. Color-changing mode
2. Stop on the current/your favorite color
3. Color-select mode (multiple solid colors to choose from)
4. Color-theme one (fades between blue, green, yellow)
5. Color-theme two (fades between pink, red, purple, orange)

AMBER GUIDE LIGHT:

The light's base produces a warm amber glow. To turn this feature ON/OFF, hold the button down for three seconds. The LEDs will flash quickly to signify that the new change is applied.

Note: Only the small LED on the end of the flexible arm is color changing. The light on the base of the light only produces an amber glow.

CLEANING INSTRUCTIONS:

Clean the light by wiping with a clean, damp cloth. Do not spray cleaning solution directly onto the light, immerse it water or place it under running water.

MADE IN CHINA

Distributed by Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114.

Questions? Contact our U.S.-based Consumer Care at 1-800-654-8483 between 7AM-8PM, M-F, Central Time.

90-day warranty. Visit www.byjasco.com for warranty details.


KEYHOLE CENTER MARK
Macra central de agujero



KEYHOLE CENTER MARK
Macra central de agujero



1 1/2 in.
41.275mm.



100%
recyclable
Separate
paper from plastic
before
recycling

100%
recyclable
paper made from 25%
post consumer waste

⚠ WARNING

- BATTERIES MAY LEAK HARMFUL LIQUIDS OR IGNITABLE MATERIALS OR EXPLODE CAUSING INJURY OR PRODUCT DAMAGE.
- DO NOT MIX OLD AND NEW OR OTHER BATTERY TYPES.
- REPLACE ALL BATTERIES AT THE SAME TIME.
- REMOVE BATTERIES IF PRODUCT IS TO BE UNUSED FOR EXTENDED PERIOD OF TIME.
- DO NOT IMMERSE IN WATER.
- CLEAN WITH A SOFT DAMP CLOTH ONLY.

60258 60259 EnSp Manual v1 4/9/21

Luz para baño con detección de movimiento

INSTALACIÓN

COLOCACIÓN DE LAS PILAS:

Retire la tapa de la luz y coloque 3 pilas AAA (no incluidas), teniendo en cuenta los polos.

MONTAJE EN EL INODORO:

Asegúrese de que el brazo flexible esté bien sujeto al puerto sobre el compartimento para pilas. Doble el brazo flexible para formar un ángulo recto y fije el gancho en el borde de la taza del inodoro. La base de la luz quedará fuera del inodoro mientras que el brazo en el interior.

Note: Asegúrese de que el brazo esté bien sujeto antes de soltarlo.

MONTAJE EN LA PARED:

Retire el brazo flexible deslizándolo hacia abajo y tirando de él con cuidado. Use los orificios de montaje en la base y los tornillos (incluidos) para montarla en una pared u otra superficie plana.

Note: Asegúrese de que el lugar de montaje sea uno seco y que pueda soportar la luz.

FUNCIONAMIENTO

DETECCIÓN DE MOVIMIENTO:

Esta luz cuenta con sensores de movimiento y activación nocturna. En condiciones de poca luz, la luz se encenderá automáticamente cuando se detecte movimiento en un campo de 4,6 m (15 ft) y en 120 grados. Se apagará la luz después de 120 segundos (2 minutos) de inactividad.

SELECCIÓN DE COLOR:

Presione el botón en la parte delantera de la luz para cambiar el color del LED dentro de la taza del inodoro. Hay varias opciones:

1. Modo de cambio de colores
2. Deténgase en el color actual o en su color favorito
3. Modo de selección de color (varios colores sólidos para elegir)
4. Color temático uno (alterna fundiendo los colores azul, verde y amarillo)
5. Color temático dos (alterna fundiendo los colores rosa, rojo, morado y naranja)

LUZ GUÍA ÁMBAR:

La base de la luz produce un brillo ámbar cálido. Para activar o desactivar esta función, mantenga presionado el botón durante tres segundos. Los LED parpadearán rápidamente para indicar que se aplicó el nuevo cambio.

Note: Solo el LED pequeño en el extremo del brazo flexible cambia de color. La luz de la base solo produce un brillo ámbar.

INSTRUCCIONES DE LIMPIEZA:

Instrucciones de limpieza: Limpie la luz con un paño limpio y húmedo. No rocíe una solución de limpieza directamente en la luz, no la sumerja en agua ni la ponga bajo agua corriente.

HECHO EN CHINA

Distribuido por Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114.

¿Preguntas? Comuníquese al 1-800-654-8483 entre las 7:00 a.m. y las 8:00 p.m. CST (hora central estándar)

Garantía de 90 días. Visite www.byjasco.com para conocer los detalles de la garantía.

⚠ ADVERTENCIA

- LAS BATERÍAS PUEDEN DERRAMAR LÍQUIDOS NOCIVOS O MATERIALES INFLAMABLES O ESTALLAR CAUSANDO LESIONES Y DAÑOS AL PRODUCTO.
- REEMPLACE TODAS LAS BATERÍAS AL MISMO TIEMPO.
- REEMPLACE LAS BATERÍAS TOTALMENTE DESCARGADAS INMEDIATAMENTE.
- quite LAS BATERÍAS SI EL DISPOSITIVO NO VA A SER UTILIZADO POR UN TIEMPO LARGO.
- NO SUMERGIR EN AGUA.
- LIMPIAR SOLAMENTE CON UN PAÑO SUAVE Y HÚMEDO.