

LIGHTS BY NIGHT

Version 1 8/25/17

Congratulations on your recent purchase of the Lights by Night Bistro Lights. Lights by Night Bistro Lights are designed to provide lighting for life with no bulbs to replace ever again! Purchase additional lights to form one continuous string up to 750 feet!

IMPORTANT: Before installation, please read all the warning statements included on the reverse side of these instructions.



In order to ensure proper installation, please follow each step below:

Step 1 - INITIAL SETUP

- 1 - Carefully unpack Bistro Lights from box. Remove the wire ties (see warning on reverse side).
- 2 - When installing Bistro Lights outside, a Ground Fault Circuit Interrupter (GFCI) receptacle must be used. Before installing, plug the Bistro Lights into the GFCI receptacle to ensure all lights work properly. IMPORTANT: Unplug the Bistro Lights prior to mounting.

Step 2 - INSTALLING BISTRO LIGHTS

- 1 - IMPORTANT: Only mount Bistro Lights to solid support structures such as joists, beams, studs or other solid mounting surfaces.
- 2 - Each Bistro Light is designed with a universal keyhole for mounting with lights hanging downward. Hardware options include screws, nails, zip ties, hooks and more (not included).
- 3 - Guide wires in compliance with local electrical and building codes must also be used to support the Bistro Lights.
- 4 - Once appropriate GFCI outlet location, mounting surface and hardware are determined, mount your Bistro Lights.
- 5 - Once you have mounted the Bistro Lights, connect the male plug into the GFCI Receptacle and place the female receptacle cover firmly over the unused outlet.



Available in multiple lengths at www.byjasco.com

Step 3 - INSTALLING MULTIPLE BISTRO LIGHT SETS

Extend the length of your lights by connecting more than one strand together to form one continuous string up to 750 feet! Simply follow the above installation steps, making sure each connection between strands is secure. Once installation is complete, place the female receptacle cover firmly over the unused outlet.

Length, feet	Bulbs	Model Number
12	6	38353
24	12	38356
48	24	38357

See reverse side for electrical rating

Step 4 - REMOVING BISTRO LIGHTS

- 1 - Always unplug Bistro Lights from their receptacle prior to removal.
- 2 - Carefully remove each light individually from the mounting hardware.
NOTE: For your safety, never pull or jerk lights from mounting hardware.
- 3 - Store lights in a dry location.

SAVE THESE INSTRUCTIONS

LIGHTS BY NIGHT

Simplify your Bistro Light experience by automating your on and off light times.

We recommend the following models available at your local retailer or at www.byjasco.com:

GE myTouchSmart Outdoor
Timer (Plug-in)
Model #26898



The GE myTouchSmart Plug-in Timer is the easiest to set timer on the market. Simply select your time and go.

GE myTouchSmart
Timer (In-Wall)
Model #26893



The GE myTouchSmart In-Wall Timer provides easy-set controls if your receptacle is controlled by a switch.

GE Bluetooth Outdoor
Smart Switch (Plug-in)
Model #13868



Wirelessly schedule and control outside lights or other devices from your smartphone or tablet.

GE Bluetooth
Smart Switch (In-Wall)
Model #13869



The GE Bluetooth In-Wall version provides the same Bluetooth control if your receptacle is controlled by a switch.

Important — please read:

Refer to the manual or visit www.byjasco.com for limitations and restrictions on warranties and the product registration information.

▲WARNING: When using outdoors use portable luminaires, basic safety precautions should always be followed to reduce the risk of fire, electrical shock and personal injury, including the following:

- Use only three-wire outdoor extension cords that have three-prong grounding plugs and grounding receptacles that accept the appliance's plug.
- Ground Fault Circuit Interrupter (GFCI) protection is to be provided on the circuit(s) or outlet(s) to be used for the wet location portable luminaire. Receptacles are available having built-in GFCI protection and are able to be used for this measure of safety.
- Use only with an extension cord for outdoor use, such as an extension cord of cord type SEW, SEOW, SEOWW, SOW, SOOW, STW, STOW, STOOW, SJEW, SJEOW, SJEOWW, SJW, SJOW, SJOOW, SJTW, SJTOW, or SJTOOW.

▲WARNING: Keep these bags away from babies and children. Do not use in cribs, beds, carriages or playpens. The thin film may cling to nose and mouth and prevent breathing.

NOTE: Ensure the Bistro Light's receptacle cover is firmly installed and well seated when not being used to connect additional strings.

Warranty Information: This Jasco product is warranted for lifetime replacement warranty on the LED light source only.

Electrical Ratings
Input: 120 V, 60 Hz

Model No.	Input watt, Max.	Location Use
GE014-OPP-5.4W	5.4W	Wet
GE014-OPP-10.8W	10.8W	
GE014-OPP-21.6W	21.6W	

**BY
JASCO®**

MADE IN CHINA / HECHO EN CHINA
**DISTRIBUTED BY JASCO PRODUCTS
COMPANY LLC, 10 E. MEMORIAL RD.,
OKLAHOMA CITY, OK 73114.**
Patents pending
Questions? Contact us at 1-800-654-8483
between 7:00AM – 8:00PM CST.



▲WARNING

RISK OF ELECTRIC SHOCK

- RECEPTACLE OUTLETS USED FOR POWERING BISTRO LIGHTS SHALL COMPLY WITH ALL NATIONAL AND LOCAL ELECTRICAL CODES. CONSULT LOCAL ELECTRICIAN IF UNSURE OF COMPLIANCE REQUIREMENTS.
- FOR USE ONLY ON GFCI PROTECTED CIRCUITS.
- DO NOT SUBMERSE.
- DO NOT USE AROUND AQUARIUMS.
- BISTRO LIGHTS ARE A WET LOCATION PRODUCT AND HAVE NO SERVICEABLE PARTS.
- DO NOT USE WITH EXTENSION CORD NEAR WATER OR WHERE WATER MAY ACCUMULATE.
- KEEP LAMPS AT LEAST 16 FEET FROM POOLS AND SPAS.
- KEEP PLUGS AND RECEPTACLES DRY.
- AVOID DAMAGE TO THE CORDS AND LAMP ASSEMBLIES DURING INSTALLATION. PERIODICALLY INSPECT THE BISTRO LIGHTS FOR PHYSICAL DAMAGE OR OTHER DAMAGE CAUSED BY OUTDOOR EXPOSURE TO THE ELEMENTS.
- REPLACE ANY DAMAGED BISTRO LIGHT STRINGS.
- DO NOT INSTALL IN LOCATIONS WHERE BISTRO LIGHTS CAN BE STEPPED ON.
- ENSURE BISTRO LIGHTS ARE UN-PLUGGED FROM POWER DURING INSTALLATION.
- BISTRO LIGHTS SHOULD BE INSTALLED OUT OF THE REACH OF CHILDREN OR NOT ALLOWING CHILDREN TO PLAY WITH THEM.
- UL RECOMMENDS TESTING GFCI CIRCUITS AND RECEPTACLES EVERY MONTH TO ENSURE PROPER OPERATION.
- DO NOT OPERATE WITHOUT BULB SECURELY SCREWED IN.

RISK OF FIRE

- BISTRO LIGHTS ARE DESIGNED TO BE MOUNTED WITH THEIR INDIVIDUAL KEYHOLE MOUNTING FEATURE. DO NOT MOUNT BISTRO LIGHTS BY USING THE MAIN ELECTRICAL CORD OR THE INDIVIDUAL DROP CORDS.
- BISTRO LIGHTS ARE DESIGNED TO BE LINKED BY USING THEIR ELECTRICAL PLUGS AND RECEPTACLES TO A MAXIMUM DISTANCE OF 350 FEET.
- BISTRO LIGHT INTERCONNECTING RECEPTACLES ARE INTENDED ONLY FOR THE LINKING OF COMPATIBLE BISTRO LIGHT STRINGS. DO NOT USE BISTRO LIGHT RECEPTACLES FOR ANY OTHER ELECTRICAL PURPOSE.
- DO NOT MOUNT BISTRO LIGHTS IN ANY POSITION WHERE THE BULB IS FACING UP.
- DO NOT ALLOW THE LED LAMP ASSEMBLIES TO BE IN CONTACT WITH COMBUSTIBLE MATERIALS. LED LAMP ASSEMBLIES SHOULD HANG FREELY AND NOT BE SUSCEPTIBLE TO REPETITIVE DAMAGE CAUSED BY ENVIRONMENTAL CONDITIONS SUCH AS WIND, RAIN, AND ICE.
- NOT INTENDED FOR INSTALLATION IN CEILINGS, SOFFITS, CABINETS, ATTICS, OR OTHER ENCLOSED SPACES.