

<b>AUDIO RECEIVER BRAND</b>	<b>AUDIO RECEIVER CODES</b>
AIWA	759, 762, 771, 836, 839, 842, 851, 860
APEX	436
BOSE	672
CARVER	745, 825
CITIZEN	746, 826
CRITERION	448
DENON	723, 737, 803, 817, 852
DELPHI	708
FISHER	734, 741, 814, 821
GOLDSTAR	686, 766
HARMON KARDON	724, 738, 804, 818
JVC	710, 733, 739, 790, 813, 819
KENWOOD	603, 683, 728, 736, 748, 752, 808, 816, 828, 832, 869
KOSS	415
MAGNAVOX	716, 734, 796, 814
MARANTZ	608, 744, 688, 824
MITSUBISHI	877
NAD	641, 659, 721, 739, 743
NORCENT	907
ONKYO	725, 731, 732, 805, 811, 812, 892
OPTIMUS	587, 667, 668, 669, 670, 671, 672, 674, 713, 667, 747, 748, 749, 751, 752, 754, 793
PANASONIC	730, 735, 791, 810, 815, 823, 824, 825, 863, 864
PHILIPS	734, 743, 744, 745, 755, 814, 823, 824, 825
PIONEER	757, 837, 866, 867, 878, 893
RADIOSHACK	706, 754, 793, 806, 865, 866, 867, 868, 875, 878, 879
RCA	449, 637, 692, 701, 715, 747, 717, 726, 772, 781, 795, 827, 845, 866, 867, 870, 871, 872, 875, 878, 879, 895
REALISTIC	742, 822
RS ORIGINAL	626, 674, 713, 726
SABA	894
SAMSUNG	454
SANYO	625, 705
SCOTT	688, 768
SHARP	591, 604, 729, 671, 679, 684, 809
SHERWOOD	626, 706, 726, 806, 858, 859
SONY	323, 698, 705, 717, 718, 719, 753, 754, 755, 756, 778, 779, 785, 797, 798, 799, 833, 834, 835, 836, 843, 909
TEAC	630, 727, 710, 807, 855, 856, 857
TECHNICS	711, 730, 735, 743, 791, 810, 815, 823, 863, 864
TEVION	448
VENTURER	665, 745
XM RADIO	708
YAMAHA	721, 722, 758, 760, 761, 766, 767, 768, 769, 801, 802, 838, 840, 841, 846, 847, 848, 849

ZENITH	405, 596, 650, 669, 676, 679, 685, 686, 704, 730, 734, 749, 759, 765, 766, 770, 784, 787, 814, 850
<b>CABLE BOX BRAND</b>	<b>CABLE BOX CODES</b>
ABC	001, 002, 003, 004, 005, 006, 007, 381, 382, 383, 384, 385, 386, 387, 461, 462, 463, 464, 465, 466
ADELPHIA	512, 596
ALLEGRO	444, 445, 524, 525
AMERICAST	447, 527
ANTRONIX	008, 009, 388, 389, 468, 469
ARCHER	008, 009, 010, 011, 388, 389, 390, 391, 468, 469, 470, 471
AT&T	511
BELL SOUTH	527
CABLETENNA	008, 388, 468
CABLEVIEW	008, 388, 468
CENTURY	011, 391, 471
CITIZEN	011, 391, 471
COLOUR VOICE	012, 013, 392, 393, 472, 473
COMCAST	511
COMTRONICS	014, 015, 474, 475
CONTEC/CONY	016, 396, 476
DIGITAL MUSIC EXPRESS	514
EASTERN	017, 397, 477
EVERQUEST	474
GARRARD	011, 391, 471
GC ELECTRONICS	009, 389, 469
GEMINI	018, 019, 049, 398, 399, 478, 479, 536
GE	469, 549
GENERAL INSTRUMENT	003, 383, 429, 431, 433, 434, 438, 448, 449, 450, 451, 461, 463, 464, 465, 509, 511, 513, 514, 518, 528, 529, 530, 531
HAMLIN	020, 021, 022, 035, 045, 400, 401, 402, 461, 480, 481, 482
HITACHI	003, 383, 463
HYTEX	002, 382, 462
INSTANT REPLAY	021
JASCO	011, 391, 471
JERROLD	001, 003, 005, 007, . 018, 023, 024, 046, 381, 383, 384, 385, 387, 398, 404, 429, 430, 446, 448, 449, 461, 463, 464, 465, 478, 484, 509, 510, 511, 518, 520, 526, 528, 529
MAGNAVOX	025, 405, 485
MEMOREX	026, 406, 486
MOTOROLA	461, 463, 464, 465, 478, 484, 509, 510, 511, 513, 514, 518, 526, 528, 529, 530, 531
MOVIE TIME	002, 027, 382, 407, 462, 487

<b>NSC</b>	002, 027, 382, 407, 462, 487
<b>OAK</b>	002, 016, 029, 382, 396, 409, 462, 476, 489
<b>PACE</b>	532
<b>PANASONIC</b>	000, 048, 380, 428, 460, 508
<b>PARAGON</b>	026, 406, 486, 488
<b>PHILIPS</b>	011, 012, 013, 0119, 025, 030, 031, 032, 471, 479, 485, 490, 491, 492
<b>PHILIPS/ MAGNAVOX</b>	391, 392, 393, 399, 405, 410, 411, 412, 471, 472, 473, 479, 485, 490, 491, 482, 503, 534
<b>PIONEER</b>	033, 034, 413, 414, 418, 478, 493, 494, 498, 506
<b>PULSAR</b>	026, 406, 486
<b>RADIO SHACK</b>	425, 505, 525, 534
<b>RCA</b>	000, 047, 049, 380, 427, 460, 471, 507
<b>REALISTIC</b>	009, 049, 389, 469
<b>REGAL</b>	022, 035, 402, 482
<b>REGENCY</b>	017, 397, 477
<b>REMBRANDT</b>	003, 383, 463
<b>RUNCO</b>	026, 406, 486
<b>SAMSUNG</b>	014, 034, 394, 414, 474, 494 006, 036, 037, 038, 386, 416, 417, 418, 466, 496, 497, 498, 506, 512, 535, 596, 607
<b>SCIENTIFIC ATLANTA</b>	498, 506, 512, 535, 596, 607
<b>SIGNAL</b>	014, 018, 394, 398, 474, 478
<b>SIGNATURE</b>	003, 383, 463
<b>SL MARX</b>	014, 394, 474
<b>SPRUCER</b>	000, 380, 460
<b>STANDARD COMPONENTS</b>	419, 499
<b>STARCOM</b>	001, 007, 018, 381, 387, 398, 461, 478, 518
<b>STARGATE</b>	014, 018, 394, 398, 474, 478
<b>STARSIGHT</b>	440, 507, 520
<b>STAR SIGHT CABLE SERVICE</b>	427, 507
<b>STARQUEST</b>	018, 398, 478
<b>STAR TRAK</b>	436, 516
<b>TANDY</b>	040, 420, 500
<b>TELEVIEW</b>	394, 474
<b>TELEWEST</b>	532
<b>TEXSCAN</b>	419, 499
<b>TIME WARNER</b>	506
<b>TOCOM</b>	384, 421, 433, 464, 501, 513, 520
<b>TOSHIBA</b>	026, 406, 486
<b>TUSA</b>	018, 398, 478
<b>TV86</b>	027, 407, 487
<b>UNIKA</b>	008, 009, 011, 388, 389, 391, 468, 469, 471
<b>UNITED ARTISTS</b>	002, 382, 462
<b>UNITED CABLE</b>	001, 381, 461 008, 009, 010, 011, 388, 389, 390, 391, 422, 468, 469, 470, 471, 502
<b>UNIVERSAL</b>	470, 471, 502
<b>VIDEOWAY</b>	044, 424, 504

	015, 025, 027, 040, 395, 405, 407, 420, 475, 485, 487, 500
<b>VIEWSTAR</b>	
<b>VIDEO TECH</b>	470, 550
	026, 050, 051, 406, 408, 423, 437, 439, 440, 441, 442, 443, 444, 445, 447, 471, 486, 488, 503, 517, 519, 520, 521, 522, 523, 524, 525, 527, 533
<b>ZENITH</b>	
<b>ZENITH NETWORK</b>	527
<b>CD PLAYER BRAND</b>	<b>CD PLAYER CODES</b>
<b>ADC</b>	580, 660
<b>ADCOM</b>	581, 634, 661, 714
<b>AIWA</b>	582, 583, 762, 662, 663, 707, 842
<b>AKAI</b>	635, 657, 750, 715, 737, 830
<b>AUDIO TECHNICA</b>	585, 665
<b>CALIFORNIA AUDIO LABS</b>	636, 716
<b>CAPETRONIC</b>	589, 669
<b>CARVER</b>	586, 587, 588, 745, 666, 667, 668, 825
<b>CASIO</b>	697, 777
<b>CITIZEN</b>	746, 826
<b>CURTIS MATHIS</b>	697, 777
<b>DENON</b>	590, 670
<b>EMERSON</b>	581, 592, 593, 661, 673
<b>FISHER</b>	587, 595, 596, 597, 638, 667, 675, 676, 677, 718
<b>GE</b>	645, 725
<b>GENEXXA</b>	592, 593, 598, 639, 673, 678, 719
<b>GOLDSTAR</b>	640, 720
<b>HARMON KARDON</b>	600, 611, 680, 691
<b>HITACHI</b>	598, 678
<b>INKEL</b>	601, 681
<b>JC PENNEY</b>	610, 697, 690, 777
<b>JVC</b>	602, 733, 682, 813
	603, 604, 605, 647, 648, 679, 683, 684, 685, 727, 728, 748, 828
<b>KENWOOD</b>	
<b>KRELL</b>	586, 666
<b>KYOCERA</b>	580, 660
<b>LUXMAN</b>	606, 607, 649, 658, 686, 687, 729, 738
<b>LXI</b>	592, 697, 777
<b>MAGNAVOX</b>	586, 651, 720, 666, 731, 800
<b>MARANTZ</b>	586, 608, 609, 652, 666, 688, 689, 732
<b>MCS</b>	610, 697, 690, 777
<b>MGA</b>	611, 691
<b>MISSION</b>	586, 666
<b>MITSUBISHI</b>	611, 612, 691, 692
<b>NAD</b>	641, 721, 743
<b>NAKAMICHI</b>	613, 614, 751, 693, 694, 831
<b>NEC</b>	610, 690
<b>NIKKO</b>	585, 593, 596, 665, 673, 676
<b>NSM</b>	586, 666

ONKYO	615, 616, 642, 731, 695, 696, 722, 811
	587, 588, 592, 598, 604, 617, 618, 619, 620, 664, 667,
OPTIMUS	668, 671, 667, 668, 678, 684, 697, 698, 699, 700, 744,
PANASONIC	636, 653, 660, 716, 733, 740, 820, 862
PHILIPS	586, 651, 745, 666, 731, 825
	598, 621, 622, 639, 757, 678, 701, 702, 719, 750, 837,
PIONEER	876
PROTON	586, 666
QUASAR	636, 716
RADIOSHACK	668, 699, 706, 750, 786, 868, 874, 876
	581, 587, 592, 623, 643, 661, 667, 703, 715, 723, 750,
RCA	764, 765, 795, 844, 845, 873, 874, 876
	581, 587, 589, 592, 593, 598, 609, 617, 619, 661, 667,
REALISTIC	669, 673, 678, 689, 697, 699
ROTEL	586, 666
RS ORIGINALS	588, 626
SAE	586, 666
SAMSUNG	661, 741
SANSUI	586, 592, 624, 643, 654, 666, 704, 723, 734
SANYO	587, 625, 638, 655, 662, 667, 705, 718, 735, 742
SCOTT	581, 592, 593, 661, 673
SEARS	592, 604, 609, 679, 684, 689, 777
SHARP	604, 599, 609, 684, 679, 689
SHERWOOD	601, 609, 618, 626, 681, 689, 698, 706, 859
SHURE	610, 690
SONY	627, 628, 712, 714, 720, 707, 708, 792, 794, 800
STS	580, 660
SYLVANIA	586, 666
SYMPHONIC	629, 709
	596, 609, 619, 629, 630, 631, 676, 689, 699, 709, 710,
TEAC	711, 856
TECHNICS	636, 653, 656, 740, 716, 733, 820, 862
THETA DIGITAL	651, 731
TOSHIBA	641, 721
VICTOR	602, 682
YAMAHA	585, 632, 633, 644, 665, 712, 713, 724, 766, 846
ZENITH	596, 650, 679, 704, 770, 676, 730, 759, 784, 850
<b>DVD/VCR COMBO BRANDS</b>	<b>DVD/VCR COMBO CODES</b>
BROKSONIC	394
CINEVISION	230, [405 245]
EMERSON	230, 456, [458 227]
FISHER	230, [416 267]
FUNAI	230, 456, [458 227]
GO-VIDEO	230, 407, 426, 455
HITACHI	[419 227]
INSIGNIA	[405 245]

JVC	151, 418
MAGNAVOX	456
PANASONIC	437
PHILIPS	183, 456
RCA	[409 225]
SAMSUNG	230, 455
SANYO	042, 191 [416 267]
SEARS	394
SONY	389
SYLVANIA	456, [458 227]
SYMPHONIC	456, [458 227]
TOSHIBA	902
WHITE WESTINGHOUSE	[458 227]
ZENITH	[405 245]
<b>DVR/SAT COMBO BRANDS</b>	<b>DVR/SAT COMBO CODES</b>
BELL EXPRESSVU	647, 655
DISH NETWORK	647, 655
ECHOSTAR	647, 655
HUGHES NETWORK	621
RCA	636, 653
PHILIPS	621
PROSCAN	636, 653
SAMSUNG	583
SONY	657, 659
ULTIMATE TV	653, 659
ZENITH	656
<b>TV/VCR COMBO BRANDS</b>	<b>TV/VCR COMBO CODES</b>
ADMIRAL	001, 115, 124, 226
AIWA	002, 008, 155, 227, 269
AKAI	254
BROKSONIC	085, 136, 310
CANDLE	014, 153
CURTIS MATHES	073, 133, 358
DAEWOO	027, 039, 054, 097, 138, [039 252] [147 257]
ELECTROHOME	254
	002, 008, 027, 036, 039, 041, 155, 198, 227, 231, 233, 254, 264, 265, 266, 310, 325, [039 252] [147 250] [147 257]
EMERSON	257]
FISHER	043, 209, 268
FUNAI	002, 008, 155, 198, 227, 231
GE	102, 117, 194, 342
GOLDSTAR	002, 008, 014, 113, 121, 153, 155, 227, 338
HITACHI	002, 155
JVC	247
INFINITY	062, 288
KONKA	157, 158, 187, 188

LG	002, 014, 113, 121, 153, 155, 227, 338
LXI	002, 155, 227
MAGNAVOX	001, 062, 115, 226, 288, 456
MEMOREX	043, 209, 268, 456
PANASONIC	138, 148, 374, 381
PHILIPS	062, 063, 212, 288, 310
PHILIPS/MAGNAVOX	103, 213, 226, 288
OPTIMUS	374, 381
QUASAR	138, 148, 374, 381
RADIOSHACK	102, 194, 227, 342
RCA	102, 117, 194, 342
REALISTIC	227
SAMSUNG	073, 129, 133, 358
SANSUI	085, 136, 310
SANYO	043, 209, 268
SHARP	001, 124, 226, 266
SONY	002, 128, 155, 380
SYLVANIA	002, 008, 155, 198, 227, 231
SYMPHONIC	002, 008, 155, 198, 227, 231
WHITE WESTINGHOUSE	002, 008, 155, 227, [138 279]
	014, 027, 036, 041, 073, 085, 097, 104, 113, 121, 133, 136, 153, 226, 227, 247, 266, 288, 310, 338, 358, [039 252] [153 245]
<b>ZENITH</b>	
<b>TV/DVD COMBO BRANDS</b>	<b>TV/DVD COMBO BRANDS</b>
ADVENT	899
APEX	[214 401]
AXION	[177 896]
BROKSONIC	394
CHANGHONG	[214 401]
CLASSIC	[214 401]
EMERSON	456
FUNAI	456
INSIGNIA	456
JVC	901
KONKA	412, 413
MAGNAVOX	456
PANASONIC	437
PHILIPS	456, [189 458]
SEARS	394
SYLVANIA	456
SYMPHONIC	456
TOSHIBA	394, 902
<b>DVR/CABLE COMBO BRANDS</b>	<b>DVR/CABLE COMBO BRANDS</b>
PIONEER	506
ROGERS	506
SCIENTIFIC ATLANTA	506

TIME WARNER	506
<b>DVR/DVD COMBO BRANDS</b>	<b>DVR/DVD COMBO BRANDS</b>
PANASONIC	387
TOSHIBA	890, 908
<b>DVD PLAYER BRAND</b>	<b>DVD PLAYER CODES</b>
ADVENT	899
AFREY	417
AIWA	376, 414
AKAI	357, 395, 435
AMES	431
	386, 390, 391, 392, 401, 424, 430, 436, 439, 445, 457,
APEX	459
A-TREND	393
AUDIOVOX	896
AXION	896
B & K	898
BLAUPUNKT	430
BODYSONIC	417
BOSE	672
BROKSONIC	394
CHANGHONG	401
CINEVISION	405
CLASSIC	401, 431
COBY	317
CRITERION	448
CURTIS INTERNATIONAL	906
CYBERHOME	393
DAEWOO	440, 441, 444
DENON	362, 400, 421
DENZEL	428
DIGITREX	445
DISNEY	458
DUAL	428, 446, 447
DVD 2000	402
ELTA	434, 435
EMERSON	396, 405, 456, 458
FISHER	378, 416
FUNAI	456, 458
GE	403, 409, 430
GOLDSTAR	396, 405
GO-VIDEO	407, 426, 431, 455
GRANDIENTE	415
GREENHILL	430
HAAZ	451, 452
HARMAN KARDON	427
HITACHI	404, 407, 419, 428
HITEKER	445



<b>INFINITY</b>	417
<b>INSIGNIA</b>	405, 456
<b>INITIAL</b>	430
<b>INTEGRA</b>	422, 442
<b>JBL</b>	427
<b>JVC</b>	161, 368, 406, 418, 901
<b>KENWOOD</b>	400, 429
<b>KISS</b>	428
<b>KLH</b>	430
<b>KONKA</b>	372, 373, 374, 375, 410, 411, 412, 413
<b>KOSS</b>	415
<b>LASONIC</b>	451, 454
<b>LENOXX</b>	435
<b>LG</b>	396, 405
<b>LINN</b>	443
<b>LITEON</b>	318
<b>MAGNAVOX</b>	162, 360, 370, 398, 408, 456, 900, 903, 904
<b>MARANTZ</b>	360, 396, 398, 405, 408, 423, 903
<b>MEMOREX</b>	446
<b>MICROSOFT</b>	403, 409
<b>MINTEK</b>	430
<b>mitsubishi</b>	163, 364, 402
<b>MUSTEK</b>	431
<b>NAD</b>	396, 405, 433
<b>NAKAMICHI</b>	432
<b>NESA</b>	430
<b>NORCENT</b>	317, 318, 319, 905, 907
<b>ONKYO</b>	422, 892
<b>OPTIMUS</b>	404
<b>ORION</b>	394
<b>ORITRON</b>	377, 415
<b>PANASONIC</b>	362, 363, 400
<b>PACIFIC</b>	446
<b>PHILIPS</b>	162, 360, 362, 370, 387, 396, 398, 400, 408, 423, 437, 755, 891
<b>PHILIPS-MAGNAVOX</b>	398, 408, 423, 900, 904
<b>PIONEER</b>	165, 366, 403, 404, 893, 897
<b>POLAROID</b>	385
<b>POLK AUDIO</b>	398, 408, 903
<b>PORTLAND</b>	435
<b>PROLINE</b>	415
<b>PROSCAN</b>	160, 365, 403, 409
<b>RADIOSHACK</b>	404, 443, 449, 453, 894, 895
<b>REOC</b>	451
<b>RCA</b>	160, 365, 403, 409, 430, 443, 449, 453, 895
<b>ROTEL</b>	406

SABA	894
SAMSUNG	369, 407, 454, 455
SAMPO	417
SANSUI	394
SANYO	416
SEARS	394
SEG	428
SHARP	359, 397
SHERWOOD	425
SHINCO	430
SHINSONIC	430
SONY	166, 320, 321, 322, 361, 389, 399, 909
SYLVANIA	456, 458
SYMPHONIC	456, 458
TEAC	404
TECHNICS	400
TECHWOOD	433
TEVION	388, 446, 447, 448, 449, 450, 451, 452
THETA DIGITAL	404
TOSHIBA	160, 360, 394, 398, 436, 447, 890, 902, 908
UNITED	449
WHARFEDALE	417, 442
WHITE WESTINGHOUSE	458
X-BOX	409
YAMAHA	362, 400, 420, 900, 904
YAMAKAWA	428, 438
ZENITH	358, 367, 396, 405, 437
<b>DVD RECORDER BRANDS</b>	<b>DVD RECORDER CODES</b>

WHERE CODES ARE SHOWN IN BRACKETS, EACH ONE CAN BE USED IF YOU HAVE 2 OR MORE IF THE SAME DEVICE.

GO-VIDEO	431
HITACHI	419
MAGNAVOX	[900], [904]
MUSTEK	431
PANASONIC	387
PHILIPS	[900], [904]
PHILIPS-MAGNAVOX	[900], [904]
PIONEER	897
POLARIOD	385
RCA	409
SONY	[302], [321], [322]
YAMAHA	[900], [904]

<b>DIGITAL/PERSONAL RECORDER BRANDS</b>	<b>DIGITAL/PERSONAL RECORDER CODES</b>
---	--

WHERE CODES ARE SHOWN IN BRACKETS, EACH ONE CAN BE USED IF YOU HAVE 2 OR MORE IF THE SAME DEVICE.

AT&T	373
PANASONIC	373

PHILIPS	[344], [345], [371]
PROSCAN	403
RCA	403, 409
REPLAY TV	373
SONIC BLUE	373
SONY	372, 372, 657
TiVo	344, 345, 371, 372, 657, 908
TOSHIBA	908
<b>HOME AUTOMATION BRANDS</b>	<b>HOME AUTOMATION CODES</b>
X10	881
<b>HOME THEATER IN A BOX BRAND</b>	<b>HOME THEATER IN A BOX CODES</b>
AIWA	[414 839]
APEX	436
BOSE	672
CRITERION	448
KOSS	415
NORCENT	907
ONKYO	892
PANASONIC	891
PHILIPS	755
PIONEER	893
RADIO SHACK	449, 894, 895, [453 879]
RCA	449, 895, [453 879]
SABA	894
SAMSUNG	454
SONY	909
TEVION	448
ZENITH	[405 787]
<b>HDTV Television Brands</b>	<b>HDTV Television Codes</b>
HITACHI 61HDX98B	632
HUGHES HTL-HD	632
MITSUBISHI SR-HD5	632
MITSUBISHI SRHD400	632
MITSUBISHI SRHD500	632
PHILIPS DSHD800R	632
PIONEER SH-D505	604
PROSCAN PSHD105	636
RCA PSHD105	636
RCA DTC-100	636
RCA DTC-210	636
RCA HD65W20	658
SAMSUNG SIR-T165	583
SAMSUNG SIR-T351	583
SONY SATHD100	623
SONY SATHD200	623
SONY SATHD300	623

TOSHIBA DST3000	641
TOSHIBA DST3100	641
TOSHIBA DW65X91	641
ZENITH HDSAT420	634
ZENITH HDSAT520	634
ZENITH DTV1080	634
<b>LASER DISC PLAYER BRAND</b>	<b>LASER DISC PLAYER CODES</b>
DENON	285, 305
PIONEER	285, 305
PROSCAN	288, 308
RCA	288, 308
SANYO	212, 232
SONY	303, 323
ZENITH	212, 323
<b>Plasma, LCD &amp; Panel Television Brands</b>	<b>Plasma, LCD &amp; Panel Television Codes</b>
BENQ	081, 083
CORNEA	50
DUKANE	059, 072
ELITE VIDEO	197
FUJITSU	197
GATEWAY	46
HAIER	81
HITACHI	059, 072
INTEGRA	181
JVC	26
LG	50
LUCE	55
MARANTZ	181
MEGATRON	59
mitsubishi	005, 151
MONIVISION	36
NEC	181
NET TV	046, 124
NORCENT	043, 216
PANASONIC	170
PHILIPS/MAGNAVOX	204
PIONEER	072, 181
PRINCETON GRAPHICS	99
RCA	31
RUNCO	181
SAMPO	046, 124
SAMSUNG	007, 076, 077
SANYO	97
SHARP	63
SONY	013, 128

TATUNG	081, 198
TEVION	198
TOSHIBA	170, 181
VIEWSONIC	046, 072
VIKING	174
VIZIO	81
YAMAHA	170
ZENETH	050, 059, 078, 131

## SATELLITE/DTV/WEB TV RECEIVER

BRAND	SATELLITE/DTV/WEB TV RECEIVER CODES
-------	-------------------------------------

WHERE CODES ARE SHOWN IN BRACKETS, EACH ONE CAN BE USED IF YOU HAVE 2 OR MORE IF THE SAME DEVICE.

AMPLICA	495, 575
BELL EXPRESSVU	647, 654
CHANNEL MASTER	497, 498, 499, 577, 578, 579
CHAPPARAL	480, 481, 500, 560, 561
CHEYENNE	481, 561
DRAKE	482, 494, 507, 562, 574, 587
	576, 586, 613, 616, 621, 622, 623, 629, 630, 632, 634,
DISH TV	636, 638, 641, 652, 653, 657, 659
DISH NETWORK	548, 588, 589, 590, 628, [647], 648, 654, [655]
DISHPRO	568, 582, 588, 589, 590, 654
DX ANTENNA	488, 502, 568, 582
ECHOSPHERE	548, 628
ECHOSTAR	508, 509, 510, 548, 588, 589, 590, 628, [647], 654, [655]
FUJITSU	511, 512, 591, 592
GE	542, 556, 622, 636, 637, 649, 650, 651, 652, 653
GEMINI	595
	484, 485, 486, 513, 562, 563, 564, 565, 564, 565, 566,
GENERAL INSTRUMENTS	593, [627], 640, [642], [643], [644], 645, 648
DSS HITACHI	552, 561, 629, 630, 632, 638, 641
	549, 550, 552, 553, 558, 621, [629], [630], [632], 633,
DSS HUGHES SATELLITE	[638], 641
JANEIL	516, 597
JERROLD	517, 597
JVC	612, 628, 648
KENWOOD	518, 598
LUXOR	519, 599
DSS MAGNAVOX	559, 576, 612, 639
MACOM STATE	520, 600
MITSUBISHI	629, 630, 632, 638, 641
MOTOROLA	648
NORSTAT	521, 522, 601
PACE	614, 615, 646
DSS PANASONIC	546, 586, 596, 626
PANSAT	584

PRIMESTAR	547, 627, 640
PHILIPS	576, 612, 621, 629, 630, 632, 638, 639, 641
PHILIPS/ MAGNAVOX	559, 576, 612, 639
PIONEER	504, 584, 604
PROSCAN	542, 556, 622, 636, 637, 650
	542, 556, 557, 622, 636, 637, 649, 650, 651, 652, 653,
DSS RCA	658
REALISTIC	487, 523, 567, 603
SAMSUNG	583, 594, 613, 616
SCIENTIFIC ATLANTA	527
SHARP	604
SIERRA I II III	481, 561
SKY NETWORK	614, 615, 646
DSS SONY	543, 585, 623, 657, 659
STARCHOICE	627, 640, 645
STAR SIGHT	553, 633
STAR TRAK	528, 608
STS	488, 489, 490, 491, 568, 570, 571
SUPER GUIDE	529, 609
TOSHIBA	492, 562, 572, 574, 587, 595, 634, 635, 641, 646, 656
TOSHIBA DSS	544, 545, 551, 624, 625, 631
ULTIMATE TV	653, 659
UNIDEN	493, 531, 573, 611, 633
DSS UNIDEN	553, 633
UNITED	597
VIDEO CIPHER II	494, 574
WEB TV	585, 612
	482, 483, 494, 507, 554, 555, 566, 562, 563, 574, 587,
ZENITH	595, 615, 617, 634, 635, 646, 656
<b>TELEVISION BRAND</b>	<b>TELEVISION CODES</b>
ABEX	185, 172
ACME	003, 010, 021, 039, 049, 050
ADA	018, 025, 004, 007, 016
ADC	001, 002, 004, 005, 003, 009
ADMIRAL	001, 173, 020, 226
ADVENT	176, 899
ADVENTURA	174
AIKO	016, 058
AIWA	195, 196, 227, 269
ALLERON	051, 046
AMARK	020
AMTRON	053, 038
AKAI	002, 150, 254
ALLERON	046, 051
AMARK	020
AMTRON	038, 053

AMSTRAD	189
ANAM NATIONAL	003, 025, 038, 042, 053, 193
AOC	004, 005, 006, 007, 009, 014, 132, 156, 175, 176, 187
APEX	214, 215, 216, 401
ARCHER	020
AUDIOVOX	038, 053
AXION	177, 896
BANG & OLUFSEN	190
BELCOR	004
BELL & HOWELL	000, 001, 031, 049, 083, 162
BENQ	081, 083
BRADFORD	038, 053
BROKSONIC	136, 147, 250, 257, 310, 394
BROKWOOD	004
CANDLE	004, 006, 008, 009, 174
CAPEHART	175
CELEBRITY	002
CENTURION	009
CETRONIC	042
CHANGHONG	214, 401
CITIZEN	001, 004, 006, 008, 009, 016, 038, 042, 053, 058, 105, 109, 171, 174, 177, 189
CLAIRTONE	014, 176
CLASSIC	042, 214, 401
CLP	059
COLOR VOICE	010
COLORTYME	004, 006, 009, 010
CONCERTO	004, 006, 009
CONCIERGE	121
CONTEC/CONY	012, 013, 014, 038, 042, 053, 176
CORNEA	050
CRAIG	038, 042, 053
CROSLEY	062
CROWN	038, 042, 053, 171
CURTIS MATHES	000, 001, 004, 006, 009, 015, 031, 049, 105, 109, 162, 171, 130, 358,
CTX	020
CXC	038, 042, 053
DAEWOO	004, 005, 006, 009, 010, 016, 017, 018, 019, 039, 042, 058, 080, 082, 083, 085, 097, 100, 126, 127, 130, 138, 171, 252, 279,
DAYTRON	004, 006, 009, 171
DIMENSIA	000, 031
DUKANE	059, 072
DUMONT	004, 121, 151
DYNASTY	042

<b>DYNATECH</b>	178
<b>ELEKTRA</b>	001
<b>ELECTROBAND</b>	002, 014, 176
<b>ELECTROHOME</b>	003, 004, 006, 009, 022, 133, 254
<b>ELITE VIDEO</b>	197
	004, 006, 009, 012, 014, 021, 023, 024, 025, 026, 027, 028, 029, 030, 031, 032, 033, 034, 035, 036, 037, 038, 039, 040, 041, 042, 043, 044, 045, 046, 047, 049, 051, 053, 116, 123, 124, 135, 147, 162, 171, 176, 177, 179, 189, 191, 198, 227, 233, 250, 252, 254, 257, 265, 266, 310, 325, 456
<b>EMERSON</b>	310, 325, 456
<b>ENVISION</b>	004, 006, 009
<b>FISHER</b>	012, 013, 048, 049, 050, 051, 110, 162, 180, 209, 268
<b>FUJITSU</b>	046, 051, 197
<b>FUNAI</b>	038, 042, 046, 051, 053, 155, 189, 198, 227, 456
<b>FUTURETEC</b>	038, 042, 053
	000, 003, 004, 006, 009, 015, 022, 031, 044, 052, 054, 055, 087, 092, 103, 107, 125, 164, 165, 166, 167, 168, 181, 342
<b>GE</b>	181, 342
<b>GIBRALTER</b>	004, 121, 151
	004, 005, 006, 009, 012, 019, 056, 057, 058, 171, 080, 133, 155, 156, 172, 227, 338
<b>GOLDSTAR</b>	133, 155, 156, 172, 227, 338
<b>GRUNDY</b>	038, 046, 051, 053, 171
<b>GUESTVISION</b>	201
<b>HAIER</b>	081, 216, 217
<b>HALLMARK</b>	004, 006, 009
<b>HARVARD</b>	038, 053
	001, 004, 006, 009, 012, 013, 059, 060, 061, 072, 088, 091, 135, 136, 137, 138, 139, 140, 141, 142, 143, 144, 145, 146, 148, 150, 179, 210
<b>HITACHI</b>	145, 146, 148, 150, 179, 210
<b>IMA</b>	038, 053
<b>INFINITY</b>	062, 288
<b>INSIGNIA</b>	456
<b>INTEGRA</b>	181
<b>INTEQ</b>	121
<b>JANEIL</b>	174
<b>JBL</b>	062
<b>JCB</b>	002
	000, 004, 005, 006, 008, 009, 012, 015, 022, 030, 031, 052, 054, 055, 058, 063, 064, 072, 087, 105, 107, 109, 128, 171, 172, 181
<b>JC PENNY</b>	128, 171, 172, 181
<b>JENSEN</b>	004, 006, 009
	012, 013, 026, 054, 055, 060, 065, 066, 067, 069, 089, 141, 157, 158, 159, 182, 197, 247, 901
<b>JVC</b>	141, 157, 158, 159, 182, 197, 247, 901
<b>KAWASHO</b>	002, 004, 006, 009
<b>KAYPANI</b>	175



KEC	042
KENWOOD	004, 006, 009, 019, 133
KLOSS NOVABEAM	068, 069, 174, 183
KONKA	011, 016, 047, 053, 066, 157, 158, 176, 412, 413
KTV	014, 021, 038, 042, 053, 070, 116, 171, 176, 177
KURAZAI	001
LG	004, 005, 009, 012, 050, 057, 080, 156, 227, 338
LODGENET	000, 001, 031, 202
LOEWE	062, 211
LOGIK	000, 001, 031, 083
LUCE	055
LUXMAN	004, 006, 009
LXI	000, 004, 006, 009, 015, 031, 049, 062, 071, 072, 073, 107, 109, 162, 181, 227
MAGNAVOX	004, 006, 008, 009, 019, 062, 068, 069, 074, 075, 076, 077, 088, 089, 130, 131, 132, 133, 134, 141, 163, 165, 183, 184, 226, 288, 456
MAJESTIC	000, 001, 031, 083
MARANTS	062
MARANTZ	004, 006, 009, 062, 078, 181
MATSUI	062
MEGATRON	004, 006, 009, 059
MEI	014, 176
MEMOREX	000, 001, 004, 006, 009, 031, 046, 049, 051, 082, 083, 135, 162, 268, 310
MGA	004, 005, 006, 009, 012, 019, 022, 046, 051, 079, 080, 082, 133, 141, 180
MIDLAND	015, 031, 054, 055, 107, 121, 151, 171, 172, 181
MINUTZ	052
MINUTZ	004, 005, 006, 009, 019, 022, 046, 051, 079, 080, 081, 082, 089, 125, 132, 133, 141, 151, 180, 254
MINUTZ	082, 089, 125, 132, 133, 141, 151, 180, 254
MITSUBISHI	082, 089, 125, 132, 133, 141, 151, 180, 254
MONIVISION	036
MONTGOMERY WARD	000, 001, 083, 131
MOTOROLA	002, 003, 173
MTC	004, 005, 006, 009, 014, 105, 109, 176, 178
MULTITECH	038, 053, 178
MULTIVISION	084
NAD	004, 006, 009, 071, 072, 109, 185
NEC	003, 004, 005, 006, 009, 010, 085, 089, 095, 141, 181
NET TV	046, 124
NIKEI	042
NIKKO	004, 006, 009, 016, 058
NORCENT	043, 216
NTC	016, 058
ONCOMMAND	201
ONKING	042

<b>ONWA</b>	038, 042, 053
<b>OPTIMUS</b>	170, 185, 374, 381
<b>OPTONICA</b>	020, 095, 173
<b>ORION</b>	035, 121, 135, 191
<b>PANASONIC</b>	003, 054, 055, 062, 070, 148, 149, 170, 171, 374, 381, 437
<b>PHILCO</b>	003, 004, 005, 006, 008, 009, 012, 019, 062, 068, 069, 074, 075, 077, 133, 183, 184
<b>PHILIPS</b>	003, 004, 006, 008, 012, 019, 046, 047, 062, 068, 069, 074, 075, 076, 086, 087, 088, 089, 133, 141, 163, 183, 184, 189, 204, 205, 206, 207, 208, 212, 213, 288
<b>PHILIPS/MAGNAVOX</b>	062, 183, 184, 204, 207, 208, 213, 226, 288
<b>PILOT</b>	004, 171
<b>PIONEER</b>	004, 006, 009, 072, 090, 091, 092, 179, 181, 185
<b>PORTLAND</b>	004, 005, 006, 009, 016, 058, 138, 171
<b>PRECISION</b>	166
<b>PRICE CLUB</b>	105
<b>PRINCETON GRAPHICS</b>	020, 099
<b>PRISM</b>	054, 055
<b>PROSCAN</b>	000, 015, 031, 107, 181
<b>PROTON</b>	004, 006, 009, 012, 093, 175, 186, 192
<b>PULSAR</b>	004, 121, 151
<b>PULSER</b>	004
<b>QUASAR</b>	003, 054, 055, 062, 070, 094, 148, 170, 171, 374, 381
<b>RADIO SHACK/REALISTIC</b>	000, 004, 006, 009, 012, 031, 038, 041, 042, 048, 049, 053, 095, 133, 155, 162, 170, 171, 172, 194, 227, 342
<b>RCA</b>	000, 003, 004, 005, 006, 007, 009, 011, 019, 031, 048, 054, 078, 082, 083, 094, 096, 098, 099, 100, 101, 102, 103, 107, 113, 129, 133, 167, 179, 181, 187, 188, 190, 191, 194, 342
<b>REALISTIC</b>	000, 004, 009, 012, 031, 041, 042, 048, 049, 053, 095, 155, 170, 172, 227
<b>RHAPSODY</b>	014, 176
<b>RUNCO</b>	111, 121, 151, 181
<b>SAMPO</b>	004, 006, 009, 012, 046, 124, 171, 172, 175
<b>SAMSUNG</b>	004, 005, 006, 007, 009, 012, 015, 017, 019, 076, 077, 080, 104, 105, 106, 109, 133, 171, 172, 358
<b>SAMSUX</b>	009, 171
<b>SANSUI</b>	135, 136, 191, 310
<b>SANYO</b>	004, 012, 013, 048, 049, 050, 080, 097, 107, 108, 110, 162, 169, 180, 209, 268
<b>SCOTCH</b>	004, 006, 009
<b>SCOTT</b>	004, 006, 009, 012, 024, 035, 038, 042, 046, 051, 053
<b>SEARS</b>	000, 004, 006, 009, 012, 013, 015, 019, 031, 046, 048, 049, 050, 051, 062, 066, 071, 072, 105, 107, 109, 110, 133, 162, 180, 181, 189, 394

	004, 006, 009, 012, 020, 029, 063, 079, 095, 111, 112, 113, 114, 122, 123, 124, 171, 173, 226, 266
<b>SHARP</b>	
<b>SHOGUN</b>	004
<b>SIGNATURE</b>	000, 001, 023, 031, 083, 115
<b>SIMPSON</b>	008
<b>SONIC</b>	014, 176
<b>SONY</b>	002, 006, 013, 071, 128, 380
<b>SOUNDESIGN</b>	004, 006, 008, 009, 038, 042, 046051, 053, 042, 046
<b>SPECTRAVISION</b>	203
<b>SQUAREVIEW</b>	189
<b>SSS</b>	004, 038, 042, 053
<b>STARLITE</b>	038, 053
<b>STAR SIGHT</b>	064
<b>SUPRA</b>	004, 082
<b>SUPREMACY</b>	174
<b>SUPREME</b>	002
<b>SVA</b>	216
	004, 006, 008, 009, 019, 062, 068, 069, 074, 075, 076, 077, 088, 116, 133, 135, 141, 161, 163, 183, 184, 189, 198, 227, 456
<b>SYLVANIA</b>	
<b>SYMPHONIC</b>	024, 033, 038, 053, 189, 198, 227, 456
<b>TANDY</b>	020, 173
<b>TATUNG</b>	003, 081, 178, 198
<b>TECHNICS</b>	004, 009, 054, 055
<b>TECHWOOD</b>	004, 006, 009, 054, 055
	000, 001, 004, 005, 006, 008, 009, 012, 013, 016, 031, 038, 042, 046, 051, 053, 058, 076, 082, 083, 105, 109, 170, 171, 174
<b>TEKNIKA</b>	
<b>TELECATION</b>	117
<b>TELERENT</b>	000, 001, 031
<b>TERA</b>	004, 186
<b>TEVION</b>	198
<b>TMK</b>	004, 006, 009
	012, 013, 049, 071, 072, 089, 095, 105, 109, 117, 118, 120, 141, 159, 160, 162, 170, 178, 181, 260, 358, 394, 902
<b>TOSHIBA</b>	
<b>TOTEVISION</b>	171
<b>UNIVERSAL</b>	052, 087
<b>VICTOR</b>	060, 066, 182
<b>VIDTECH</b>	004, 005, 006, 009
<b>VIEWSONIC</b>	046, 072
<b>VIKING</b>	174
<b>VIZIO</b>	081
	000, 001, 004, 005, 006, 008, 009, 019, 024, 031, 033, 046, 051, 052, 062, 068, 069, 074, 075, 076, 083, 087, 088, 095, 119, 120, 133, 184
<b>WARDS</b>	
<b>WHITE WESTINGHOUSE</b>	080, 097, 100, 130, 138, 155, 227, 279

<b>YAMAHA</b>	004, 005, 006, 009, 019, 133, 170
<b>YUPITERU</b>	42
	000, 001, 004, 009, 023, 038, 039, 050, 058, 059, 064, 078, 083, 091, 111, 121, 131, 134, 135, 136, 151, 152, 153, 154, 226, 227, 245, 247, 252, 266, 288, 310, 338, 358
<b>ZENETH</b>	358
<b>VCR BRAND</b>	<b>VCR CODES</b>
<b>ACCELE</b>	354
<b>ADMIRAL</b>	001, 206, 226
<b>ADVENTURA</b>	026, 231, 251
<b>AIKO</b>	027, 232, 252
<b>AIWA</b>	002, 026, 207, 231, 249, 227, 245, 251, 269 003, 004, 005, 007, 008, 208, 209, 210, 211, 213, 227, 228, 229, 230, 231, 233, 234, 254, 303, 316, 317, 336, 337
<b>AKAI</b>	337
<b>ALLERGRO</b>	223, 227, 309, 243, 247, 329
<b>AMERICAN HIGH</b>	021, 226, 265, 246, 285, 292, 329
<b>ASHA</b>	013, 218, 354, 359
<b>AT&amp;T</b>	373
<b>AUDIO DYNAMICS</b>	009, 010, 214, 328, 234, 376, 377
<b>AUDIOVOX</b>	014, 219, 239, 245, 348
<b>BELL &amp; HOWELL</b>	011, 248, 268
<b>BEAUMARK</b>	013, 218, 354, 359 012, 025, 217, 230, 236, 237, 250, 256, 257, 269, 290, 237, 250, 256, 289, 310, 394
<b>BROKSONIC</b>	237, 250, 256, 289, 310, 394
<b>CALIX</b>	014, 219, 239, 254 013, 014, 015, 016, 017, 018, 019, 214, 218, 219, 220, 221, 222, 224, 234, 239, 240, 241, 242, 244, 245, 354, 359
<b>CANDLE</b>	359
	021, 022, 114, 225, 226, 265, 292, 319, 320, 246, 285, 339, 340
<b>CANNON</b>	339, 340
<b>CAPEHART</b>	020, 110, 309, 315, 329
<b>CARVER</b>	062, 267, 287
<b>CCE</b>	027, 061, 232, 266, 252, 286, 356
<b>CINEVISION</b>	245 013, 014, 015, 016, 017, 018, 019, 027, 214, 218, 219, 220, 221, 222, 224, 232, 234, 239, 240, 241, 242, 244, 245, 252, 354, 359
<b>CITIZEN</b>	245, 252, 354, 359
<b>COLORTYME</b>	009, 214, 234
<b>COLT</b>	061, 266, 286, 356 013, 014, 023, 061, 218, 219, 228, 266, 239, 245, 248, 286, 354, 356, 359
<b>CRAIG</b>	286, 354, 356, 359
	000, 002, 009, 013, 016, 018, 021, 022, 024, 115, 205, 207, 214, 218, 221, 225, 226, 229, 265, 225, 227, 234, 241, 246, 249, 285, 287, 292, 320, 334, 340, 354, 358, 359
<b>CURTIS MATHES</b>	359

<b>CYBERNEX</b>	013, 218, 354, 359
	015, 017, 019, 025, 026, 027, 028, 110, 220, 222, 224, 230, 231, 232, 233, 315, 240, 242, 244, 250, 251, 252, 253, 279, 334
<b>DAEWOO</b>	
<b>DAYTRON</b>	110, 315
<b>DBX</b>	009, 010, 214, 234, 328, 234, 348, 376, 377
<b>DIMENSIA</b>	000, 205, 225, 255
<b>DYNATECH</b>	002, 026, 207, 227, 231, 251
<b>ELECTROHOME</b>	014, 029, 219, 234, 245, 277, 251, 239, 254
<b>ELECTROPHONIC</b>	014, 219, 239, 245
	002, 014, 015, 021, 024, 025, 026, 029, 030, 032, 033, 034, 035, 036, 037, 038, 039, 040, 041, 042, 044, 045, 047, 065, 105, 113, 116, 117, 130, 207, 211, 217, 219, 220, 226, 227, 229, 230, 231, 233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 248, 249, 250, 251, 252, 254, 255, 256, 257, 259, 261, 262, 263, 265, 266, 268, 269, 270, 272, 285, 289, 290, 292, 301, 310, 321, 325, 330, 341, 354, 359, 456
<b>EMERSON</b>	011, 023, 048, 049, 050, 051, 052, 118, 214, 228, 234, 248, 253, 254, 255, 267, 234, 248, 267, 268, 273, 274, 275, 287, 304
<b>FISHER</b>	
<b>FUJI</b>	021, 119, 209, 226, 265, 229, 246, 285, 292
<b>FUNAI</b>	002, 026, 207, 213, 231, 227, 233, 251, 456
<b>GARRARD</b>	026, 231, 251
	000, 013, 021, 022, 0536, 115, 120, 205, 218, 225, 226, 246, 258, 265, 278, 285, 292, 311, 320, 322, 325, 340, 342, 345, 354, 359
<b>GE</b>	004, 005, 006, 012, 019, 056, 057, 058, 155, 156, 171, 172, 214, 219, 227, 245, 234, 239, 326, 338, 346
<b>GOLDSTAR</b>	
<b>GRADIENTE</b>	026, 231, 251
<b>GO-VIDEO</b>	339, 348, 345, 359, 368, 375, 407, 426, 455
<b>HARLEY DAVIDSON</b>	026, 231, 251
<b>HARMON KARDON</b>	009, 214, 234, 254, 273, 293
<b>HARWOOD</b>	061, 266, 286, 356
<b>HEADQUARTER</b>	011, 248, 268
	002, 055, 056, 057, 107, 111, 120, 122, 207, 227, 280, 282, 260, 262, 303, 312, 316, 322, 325, 327, 336, 345, 347, 349, 350, 369, 370
<b>HITACHI</b>	
<b>HI-Q</b>	023, 228, 248
<b>INFINITY</b>	288
<b>INSIGNIA</b>	245
<b>INSTANT REPLAY</b>	021, 213, 226, 227, 265, 233, 246, 285, 292
<b>INTEQ</b>	219, 239, 245
<b>JCL</b>	021, 226, 265, 246, 285, 292

	009, 010, 011, 013, 014, 021, 022, 055, 056, 058, 059, 060, 107, 118, 214, 218, 219, 225, 234, 239, 245, 248, 260, 265, 268, 280, 285, 292, 303, 312, 328, 316, 320, 323, 332, 336, 340, 343, 348, 354, 359, 369, 376, 377
<b>JC PENNY</b>	
<b>JENSEN</b>	111, 260, 280, 303, 316, 336, 369
	009, 010, 011, 018, 058, 111, 123, 214, 227, 234, 247, 248, 316, 328, 234, 247, 268, 303, 336, 348, 376, 377, 418
<b>JVC</b>	
	009, 010, 011, 018, 058, 111, 123, 214, 221, 248, 268, 316, 328, 234, 247, 268, 303, 336, 348, 376, 377
<b>KENWOOD</b>	
<b>KLH</b>	061, 266, 336, 286, 356
<b>KODAK</b>	014, 021, 219, 226, 245, 239, 246, 265, 285, 292
<b>LG</b>	227, 329, 338
<b>LLOYD</b>	002, 026, 207, 231, 227, 251
<b>LOGIK</b>	061, 266, 286, 356
<b>LXI</b>	014, 219, 227, 239, 245
	021, 022, 062, 063, 104, 108, 124, 225, 226, 265, 267, 292, 309, 311, 320, 329, 246, 285, 287, 288, 329, 331, 340, 349, 246, 285, 287, 329, 331, 340, 349, 456
<b>MAGNAVOX</b>	
<b>MAGNIN</b>	013, 218, 354, 359
	009, 010, 011, 016, 018, 021, 058, 062, 064, 214, 221, 226, 234, 248, 265, 267, 268, 269, 287, 289, 292, 319, 328, 246, 285, 287, 329, 331, 339, 340, 349, 376, 377
<b>MARANTZ</b>	
<b>MARTA</b>	014, 219, 239, 245
<b>MATSUSHITA</b>	021, 226, 265, 246, 285, 292
<b>MEGATRON</b>	006, 059
<b>MEI</b>	021, 226, 265, 246, 285, 292
	001, 002, 011, 013, 014, 021, 023, 026, 104, 206, 207, 218, 219, 226, 227, 228, 231, 239, 245, 246, 248, 251, 265, 268, 285, 287, 292, 304, 309, 310, 317, 329, 337, 354, 359
<b>MEMOREX</b>	
<b>MGA</b>	029, 065, 113, 234, 270, 254, 290
<b>MGN TECHNOLOGY</b>	013, 218, 354, 359
<b>MIDLAND</b>	053, 258, 278
<b>MINOLTA</b>	055, 056, 107, 260, 312, 280, 332, 369
	029, 055, 056, 065, 066, 067, 069, 070, 071, 072, 073, 074, 106, 113, 123, 234, 254, 260, 270, 271, 273, 274, 275, 276, 278, 279, 328, 254, 276, 277, 280, 290, 291, 293, 294, 295, 296, 298, 299, 348, 369, 376, 377
<b>MITSUBISHI</b>	
<b>MONTGOMERY WARD</b>	001, 075, 206, 280, 226, 300
<b>MOTOROLA</b>	001, 021, 206, 226, 265, 226, 246, 285, 292
<b>MTC</b>	002, 013, 026, 207, 218, 231, 227, 251, 354, 359
	002, 013, 026, 053, 061, 207, 218, 227, 231, 251, 258, 266, 227, 251, 278, 286, 354, 356, 359
<b>MULTITECH</b>	

	009, 010, 011, 016, 018, 058, 064, 076, 078, 079, 111, 123, 214, 221, 229, 234, 248, 249, 254, 268, 269, 276, 277, 280, 281, 282, 283, 289, 290, 291, 293, 294, 295, 301, 302, 303, 316, 328, 376, 377
<b>NEC</b>	
<b>NIKKO</b>	014, 219, 239, 245
<b>NOBLEX</b>	013, 218, 354, 359
<b>OLYMPUS</b>	021, 226, 265, 246, 285, 292
<b>OPTIMUS</b>	001, 014, 206, 219, 226, 239, 245, 314, 339, 341, 342, 354, 359, 361, 362, 363, 374, 381
<b>OPTONICA</b>	096, 280, 339, 300, 354, 359
<b>ORION</b>	236, 256, 310
<b>PANASONIC</b>	021, 022, 109, 125, 126, 127, 225, 226, 239, 265, 292, 314, 320, 330, 343, 353, 359, 361, 362, 363, 373, 374, 016, 055, 156, 107, 120, 221, 234, 241, 260, 280, 312, 325, 332, 345, 369
<b>PENTAX</b>	
<b>PENTEX RESEARCH</b>	018, 214, 234
<b>PHILCO</b>	021, 022, 062, 063, 225, 226, 246, 265, 267, 285, 287, 292, 320, 340
<b>PHILIPS</b>	021, 062, 096, 124, 226, 246, 265, 267, 280, 285, 287, 288, 292, 300, 311, 328, 329, 331, 333, 344, 345, 349, 351, 371, 378, 383, 456
<b>PHILIPS/ MAGNAVOX</b>	226, 287, 288, 328, 333
<b>PILOT</b>	014, 219, 239, 245
<b>PIONEER</b>	010, 055, 080, 081, 123, 260, 280, 285, 286, 305, 306, 328, 343, 348, 369, 376, 377
<b>PORTLAND</b>	016, 017, 019, 110, 221, 222, 224, 315, 241, 242, 244
<b>PROSCAN</b>	000, 205, 225, 308
<b>PROTEC</b>	061, 266, 286, 356
<b>PULSAR</b>	104, 309, 329
<b>QUARTER</b>	011, 248, 268
<b>QUARTZ</b>	011, 248, 268
<b>QUASAR</b>	021, 022, 125, 225, 226, 265, 320, 330, 246, 285, 292, 340, 350, 363, 374, 381
<b>RADIO SHACK/REALISTIC</b>	001, 002, 011, 013, 014, 021, 022, 023, 026, 029, 049, 050, 096, 205, 206, 207, 218, 219, 226, 228, 231, 234, 248, 254, 255, 265, 280, 314, 317, 320, 341, 342, 343, 225, 226, 227, 239, 246, 248, 251, 254, 268, 274, 275, 285, 300, 337, 340, 342, 359, 361, 362, 363, 225, 226, 227, 239, 246, 248, 251, 254, 268, 274, 275, 285, 300, 337, 340, 342, 359, 361, 362, 363
<b>RADIX</b>	014, 219, 239, 245
<b>RANDEX</b>	014, 219, 239, 245

	000, 003, 013, 021, 055, 056, 082, 083, 084, 085, 086, 087, 088, 089, 090, 091, 107, 115, 120, 125, 205, 208, 218, 225, 226, 227, 228, 239, 245, 246, 248, 251, 254, 260, 265, 268, 274, 278, 280, 285, 287, 288, 289, 291, 292, 293, 294, 295, 296, 300, 307, 308, 309, 311, 312, 313, 314, 315, 316, 320, 325, 330, 332, 335, 337, 340, 342, 345, 350, 354, 359, 361, 362, 363, 369
<b>RCA</b>	
<b>REPLAY</b>	353, 373
<b>RICOH</b>	128, 333, 353
<b>RUNCO</b>	104, 309, 329
	005, 013, 015, 033, 053, 112, 210, 218, 220, 230, 238, 240, 258, 260, 278, 280, 317, 334, 337, 339, 354, 358, 359, 369, 455
<b>SAMSUNG</b>	
<b>SANKY</b>	001, 104, 206, 309, 226, 329
<b>SANSUI</b>	010, 092, 111, 123, 297, 316, 328, 336, 348
<b>SANYO</b>	011, 013, 023, 218, 228, 248, 267, 268, 304, 354, 359 012, 015, 025, 032, 038, 065, 093, 116, 217, 220, 230, 237, 240, 243, 250, 257, 263, 270, 290, 298, 318, 321, 341
<b>SCOTT</b>	
	011, 014, 021, 023, 048, 049, 050, 051, 055, 056, 107, 118, 219, 226, 228, 239, 245, 246, 248, 253, 254, 255, 260, 265, 267, 268, 273, 274, 275, 280, 285, 287, 292, 312, 323, 332, 343, 363, 369, 394
<b>SEARS</b>	
	001, 002, 017, 029, 094, 095, 096, 206, 207, 222, 226, 227, 234, 239, 242, 246, 248, 254, 266, 268, 273, 274, 275, 280, 285, 287, 300, 340, 341, 360, 361
<b>SHARP</b>	
	004, 056, 061, 098, 209, 229, 260, 266, 280, 286, 333, 337, 353, 356, 357, 369
<b>SHINTOM</b>	
<b>SHOGUN</b>	013, 218, 354, 359
<b>SIGNATURE</b>	002, 207, 227, 354
<b>SINGER</b>	021, 061, 226, 265, 266, 246, 285, 286, 292, 356
<b>SONIC BLUE</b>	373
	344, 345, 346, 352, 353, 364, 365, 366, 372, 379, 380, 389
<b>SONY</b>	
	021, 107, 226, 260, 265, 312, 246, 280, 285, 292, 332, 369
<b>STS</b>	
	002, 021, 022, 026, 062, 063, 065, 124, 207, 227, 231, 233, 251, 265, 267, 270, 285, 287, 290, 320, 340, 349, 456
<b>SYLVANIA</b>	
<b>SYMPHONIC</b>	002, 026, 207, 231, 227, 233, 236, 251, 456
<b>TANDY</b>	002, 011, 207, 248, 227, 268
<b>TASHIKO</b>	014, 219, 239, 245
<b>TATUNG</b>	058, 111, 303, 316, 336
	002, 026, 058, 085, 111, 207, 231, 316, 227, 251, 303, 336
<b>TEAC</b>	
<b>TECHNICS</b>	021, 109, 226, 265, 314, 246, 285, 292



	002, 014, 021, 026, 100, 129, 207, 219, 226, 227, 231, 239, 245, 246, 251, 265, 285, 292, 305, 325
<b>TEKNIKA</b>	
<b>TiVo</b>	351, 352, 371, 372
<b>TMK</b>	013, 024, 047, 218, 229, 252, 249, 272, 301, 354, 359
	015, 049, 051, 055, 065, 093, 116, 220, 240, 254, 260, 261, 267, 270, 274, 287, 290, 298, 318, 321, 341, 358, 369, 902,
<b>TOSHIBA</b>	
<b>TOTEVISION</b>	013, 014, 218, 219, 239, 245, 354, 359
<b>UNITECH</b>	013, 218, 354, 359
	009, 010, 015, 016, 214, 220, 221, 328, 234, 240, 241, 348, 376, 377
<b>VECTOR RESEARCH</b>	
<b>VICTOR</b>	010, 328, 348, 376, 377
	009, 010, 015, 016, 113, 214, 220, 221, 234, 328, 240, 254, 274, 280, 287, 290, 318, 341, 376, 377
<b>VIDEO CONCEPTS</b>	
<b>VIDEOSONIC</b>	013, 218, 354, 359
	001, 002, 013, 014, 015, 021, 023, 026, 029, 055, 056, 061, 096, 101, 102, 103, 107, 116, 206, 207, 218, 219, 220, 225, 226, 227, 228, 231, 234, 239, 240, 245, 246, 248, 251, 254, 260, 265, 266, 280, 285, 306, 312, 321, 354, 369
<b>WARDS</b>	
<b>WHITE WESTINGHOUSE</b>	207, 213, 227, 233, 251, 279, 292, 356
<b>XR-1000</b>	021, 026, 061, 226, 231, 265, 266, 246, 251, 285, 286
	009, 010, 011, 018, 058, 111, 214, 234, 248, 303, 316, 328, 234, 268, 336, 348, 376, 377
<b>YAMAHA</b>	
	004, 098, 104, 119, 128, 209, 212, 215, 219, 223, 226, 227, 229, 232, 235, 239, 243, 245, 247, 252, 266, 281, 283, 284, 288, 290, 309, 310, 324, 328, 329, 333, 338, 344, 347, 348, 353, 358, 368, 370, 376, 377
<b>ZENITH</b>	