



# LED Motion Sensing Light

- Ideal for bedrooms, kitchens, basements, attics, closets and under cabinets
- No bulbs to replace
- Two Mounting Options : 1 ) Magnetic back mounts to most metal surfaces or, 2) Keyhole for wall or under cabinet mounting
- Requires 3 "AA" batteries (not included)
- For indoor use only
- Not for use in wet or damp locations
- 4 inch detection range decreases accidental activation

## Operation

### For Manual Setting

- 1) To turn on, move the switch to the On position.
- 2) To turn off, move the switch to the Off position.

### For Motion Sensing Setting

- 1) Move the switch to the "Auto" position.
- 2) To turn the light on low, wave hand once in front of sensor.
- 3) To turn the light on high, wave hand in front of sensor twice.
- 4) To turn the light off, wave hand under or in front of the sensor twice if on low, and once if on high.

## Battery Installation:

To open, turn top of unit counter clockwise and insert 3 "AA" size batteries noting polarity. **IMPORTANT:** Different types of batteries or new and used batteries should not be mixed. Exhausted batteries should be removed from the fixture and disposed of properly.

- Ideal para recámaras, cocinas, sótanos, áticos y armarios o debajo del montaje del gabinete
- Ningun bombillo para substituir
- La parte posterior magnética que monta dos Options—  
1) Monta a la mayoría de las superficies del metal o, a,  
2) Ojos de la cerradura para la pared o debajo del montaje del gabinete
- Requiere 3 baterías tipo "AA" (no incluidas)
- Para uso interior únicamente
- No para uso en lugares húmedos o mojados
- El Radio de detección de 4 pulgadas disminuye la activación accidental

## Operación:

### Para Puesta Manual

- 1) Para prender, mueva al interruptor a la posición ON.
- 2) Para apagar, mueva el interruptor a la posición OFF.

### Para la Posición Sensor de Moción

- 1) Mueva el interruptor a la posición AUTO.
- 2) Para poner la luz en BAJA, pase la mano una vez por debajo o enfrente del sensor.
- 3) Para poner la luz en ALTA, pase la mano por debajo o enfrente del sensor dos veces.
- 4) Para apagar la luz, pase la mano por debajo o enfrente del sensor dos veces si está en BAJA o una vez si esta en ALTA.

### Instalación de las baterías:

Abra el compartimiento de las baterías e inserte 3 baterías tipo "AA" observando la polaridad. **IMPORTANTE:** No se deben mezclar diferentes tipos de baterías, o baterías nuevas con las usadas. Las baterías gastadas deben de ser removidas del dispositivo y desechadas correctamente.



Made in China/Hecho en China



is a trademark of General Electric Company and is used under license to Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114.

This Jasco product comes with a limited lifetime warranty. Visit [www.jascoproducts.com](http://www.jascoproducts.com) for details.

Este producto de Jasco Products tiene una garantía limitada de por vida. Visite [www.jascoproducts.com](http://www.jascoproducts.com) para más detalles.

