
97942



55-in-1

High Speed USB 2.0 Card Reader/Writer User's Manual



www.jascoproducts.com

For technical support contact Jasco Products at 1-800-654-8483

Introduction

Thank you for purchasing the GE branded High Speed USB 2.0 55-in-1 Card Reader/Writer! You can now easily and conveniently read from and write to all major card types.

Package Includes

USB 2.0 55-in-1 Card Reader/Writer
6ft USB Mini Device Cable
Instruction Manual

System Requirements

One USB port
Compatible with Windows®, 2000, XP and Vista; Mac® OS 9.X–10.X

Features

- Compatible with 55 card types
- Easy to use – just drag and drop files and folders
- Portable and easily accessible on your desktop
- Conserves the battery life of your digital devices
- Supports data transfer rates up to 480 Mbps
- USB 1.1 and USB 2.0 Compatible*

* Connecting to a USB 1.1 port will limit the data transfer rate to a maximum of 12 Mbps

Compatible Cards

- CF I, CF II, CF I WA, CF I ELITE PRO, CF PRO, CF PRO II, CF Ultra II, HS CF, CF Extreme, CF Extreme III, CF Extreme IV
- IBM MD, Hitachi MD, MAGICSTOR
- MS, MS MG, MS PRO, MS PRO EXTREME, MS PRO MG, MS DUO, MS DUO MG, MS PRO DUO, MS PRO DUO ULTRA, MS PRO DUO MG, MS PRO ULTRA II, MS ROM, MS MEMORY SELECT FUNCTION, MS DUO HS, MS PRO EXTREME III, MS PRO HS, MS PRO DUO MG HS, M2
- XD Picture Card™, XD H Type™, XD M TYPE™
- SD, SD PRO, SD ELITE PRO, SD ULTRA, SD ULTRA II, SD EXTREME, SD EXTEREME III, SD HS 150X, SDHC 2.0, MINI SD
- T-Flash, Micro SD
- MMC, MMC 4.0, HS MMC, RS MMC, RS MMC 4.0, HS RS A15MMC, MMC MOBILE , MMC PLUS 200X

Installation

Windows® 2000, XP, Vista or Mac® OS 9.X or 10.X

NO DRIVER IS REQUIRED.


1. Plug the mini USB plug of the cable into the mini USB port on the card reader.
2. Plug the standard USB plug of the cable into your computer or hub.
3. Your computer will detect your card reader, and may automatically load additional drivers for it.
4. The card reader will show up as four removable storage drives on your computer. This can be seen in "My Computer".

-
5. Insert your card into the appropriate slot on your card reader following the guidelines in the section below.

Note: If the card is not able to be read or you incur an error, you may not have allowed enough time for all of the additional drivers to load. Remove and re-insert the card.

Card Slot Identification

Please refer to the diagram when locating the appropriate slot for each card type. Do not force the card into any slot. The card must be inserted into the correct slot with the correct orientation to avoid damage to your card and the card reader.



Technical Support

For technical support, please visit our website: www.jascoproducts.com

ONE YEAR LIMITED WARRANTY

Jasco Products Company warrants this product to be free from manufacturing defects for a period of one year from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit. This warranty is in lieu of all other warranties express or implied. Some states do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state. If unit should prove defective within the warranty period, return prepaid with dated proof of purchase to:

Jasco Products Company
10 East Memorial
Oklahoma City, OK 73114

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

-
- (1) Reorient or relocate the receiving antenna.
 - (2) Increase the separation between the equipment and the receiver.
 - (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - (4) Consult the dealer or an experienced radio/TV technician for help.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Distributed for GE
by Jasco Products Company
10 E. Memorial, Oklahoma City, OK 73114
www.jascoproducts.com