



Super Mini Retractable Mouse

Instruction Manual
98820



www.jascoproducts.com

Package Contents

- Super Mini Retractable Mouse
- Instruction Manual

System Requirements

- Windows® 2000, XP, Vista, Windows 7
- Mac 10.1 or higher
- Available USB Port

Installation

Connect the Super Mini Retractable Mouse to an available USB port on your computer or USB hub.

How to use the retractable USB cord

Quick and easy cord-winder avoids tangles and is ideal for travel. To use, pull cord from both ends to desired length. When done, pull cord from both ends gently until it is fully extended; pull both ends gently again, and let it smoothly rewind the cord.

Two Year Limited Warranty

Jasco Products Company warrants this product to be free from manufacturing defects for a period of two years from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit. This warranty is in lieu of all other warranties express or implied. Some states do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state. If unit should prove defective within the warranty period, return prepaid with dated proof of purchase to:

Jasco Products Company

10 E Memorial Rd., Oklahoma City, OK 73114

FCC Statement

Notice: Federal Communications Commission (FCC) requirements, Part 15 This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes of modifications not expressly approved by the grantee of this device could void the users authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



is a trademark of General Electric Company and is used under license to Jasco Products Company LLC, 10 E. Memorial Road, Oklahoma City, OK 73114



Super Mini Mouse Retráctil

Manual de instrucciones
98820



www.jascopeproducts.com

Contenido del paquete

- Super Mini Mouse Retráctil
- Manual de instrucciones

Requisitos del sistema

- Windows® 2000, XP, Vista y Windows 7
- Mac 10.1 o superior
- Puerto USB disponible

Instalación

Conecte el mini mouse óptico retráctil en un puerto USB disponible en el computador o en un concentrador de USB.

Cómo utilizar el cable retráctil

Su sistema para enrollar el cable rápida y fácilmente ayuda a evitar los enredos de cable y lo hace ideal para viajar. Para utilizarlo, hale el cable de ambos extremos hasta llegar a la longitud deseada. Cuando termine de utilizar el mouse, hale el cable de ambos extremos suavemente hasta que haya salido por completo; luego, hale ambos extremos de nuevo y deje que el cable se enrolle fácilmente.

Garantía limitada de dos años

Jasco Products Company garantiza que este producto está libre de defectos de fabricación durante un periodo de dos años a partir de la fecha original de compra por parte del consumidor. Esta garantía se limita a la reparación o reemplazo de este producto solamente y no se extiende a daños derivados o accidentales causados a otros productos que se usen con esta unidad. Esa garantía sustituye a todas las demás garantías explícitas o implícitas. Algunos estados no autorizan limitaciones en cuanto a la duración de una garantía implícita ni permiten la exclusión o limitación por daños accidentales o derivados; por tanto, puede que las anteriores limitaciones no se apliquen en su caso. Esta garantía le da a usted derechos específicos, y otros que varían dependiendo del estado en el que usted viva. Si dentro del periodo de garantía, la unidad resultare defectuosa, por favor envíela con porte pagado y factura de compra a:

Jasco Products Company

10 E Memorial Rd., Oklahoma City, OK 73114

Declaración de la FCC

Notificación: Requisitos de la Comisión Federal de Comunicaciones (FCC por sus siglas en inglés), parte 15

Este equipo ha sido probado y cumple con los límites de un dispositivo digital clase B, de conformidad con la parte 15 del reglamento de la FCC. Dichos límites fueron diseñados para brindar una protección suficiente contra la interferencia nociva en residencias. Este equipo genera, utiliza y puede emitir energía de radiofrecuencia y, si no se instala y se utiliza de conformidad con las instrucciones, puede generar interferencia nociva a las comunicaciones de radio. Sin embargo, no hay garantía de que no se presente interferencia en un lugar particular. Si este equipo genera interferencia nociva con la recepción de radio o televisión, lo que puede determinarse apagando y encendiendo el equipo, el usuario puede corregir la interferencia de una de las siguientes maneras:

- Reorientar o reubicar la antena receptora.
- Aumentar la separación entre el equipo y el receptor.
- Conectar el equipo en una toma que esté en un circuito distinto del circuito en el que está conectado el receptor.
- Consultar al distribuidor o a un técnico de radio y televisión con experiencia.

PRECAUCIÓN: Los cambios o modificaciones que no estén aprobados expresamente por el fabricante de este dispositivo podrían invalidar la autoridad del usuario para operar el equipo. Este dispositivo cumple con la parte 15 del reglamento de la FCC. Su operación está sujeta a las siguientes dos condiciones: (1) no es probable que este dispositivo genere interferencia nociva, y (2) este dispositivo debe aceptar cualquier interferencia recibida, inclusive la interferencia que pueda provocar un funcionamiento inadecuado.



es una marca comercial de General Electric Company, utilizada bajo licencia por Jasco Products Company LLC, 10 E. Memorial Road, Oklahoma City, OK 73114